

RESISTORS NUMBER CODE

No.	Location	Prev#	Function	Page
Res1	FJB	563205	ABS	16.1_ABS2B
Res3	RJB	563593	120R Term. Resis.	6.1_MuxNetwork0A
Res4	RightHandConsole	563593	120R Term. Resis.	6.1_MuxNetwork4C
Res5	Dash	563593	120R Term. Resis.	6.1_MuxNetwork0E
Res6	FJB	563593	120R Term. Resis.	6.1_MuxNetwork2C
Res7	FJB	563593	120R Term. Resis.	7.1_Mux_Power4B
Res8	EntranceDoorCeiling	563436	VoltageDropRes	18.1_Defroster2D
Res9	DashBoard	100R	CurrentLimitRes	10.1_Cluster1D
Res10	RJBCloseECU	562470	SignalDropRes	15.1_Transmission2A
Res11	EntranceDoorCeiling	563436	VoltageDropRes	18.1_Defroster3D
Res12	EngineCmpt.	563593	120R Term. Resis.	14.1_ECM_Motor3B
Res13	RJB	563154	ExcitationresistorAlt.1	3.2_EngineStart_ChrgSyst1D
Res14	RJB	563154	ExcitationresistorAlt.2	3.2_EngineStart_ChrgSyst1E