

MULTIPLEX DEVICES LIST

Device ID	Description	Name	Module ID	Module Pin#	Page
A24	Driver Defroster Fan Motor	O_DrvDefFanMo	A47	J1:1	18.1
A30	Passenger defrost fan speed control	O_RHDefrostFan	A47	J1:7	18.1
A31	Keyless door unlock signal	I_KeylessDrUnl	A41	J1:4	29.1
A31		I_KeylessEntReq	A41	J1:21	29.1
A31	Keyless intrusion signal	I_KeylessIntru	A41	J1:7	29.1
A31	Keyless lock all doors signal	I_KeylessLockAll	A41	J1:19	29.1
A31	Keyless luggages doors unlock signal	I_KeylessLuggUnl	A41	J1:18	29.1
A31	Keyless panic button signal	I_KeylessPanic	A41	J1:6	29.1
A31		I_KeylessPanic2	A41	J1:1	29.1
A31		O_KeylessPwr	A44	J1:6	29.1
A36		O_WakeUpA41	A41	J1:16	9.1
A41	Wake up signal (Fire alarm, horn, keyless module)	I_WakeUp	A36	JB:5	9.1
A8	Check Engine Signal	I_ChkEngSe	A42	J1:10	14.1
A8	Stop Engine Sensor	I_StopEngSe	A42	J1:9	14.1
A9	Signal Abs Warning from ABS Module	I_AbsSignalWrn	A36	JB:16	16.1
C360	Backup Monitor Signal	O_BackUpMon	A44	J1:7	
CC2		O_VehicleSpeed	A36	JA:19	21.1
L16	Driver Light Bulb	O_DriverLtLb	A47	J1:6	19.1
L17	Entrance Door Light Bulb	O_EntDorLtLb	A47	J1:8	29.1
L176-L177-L178-L179-L180-L181-L182-L183-L287-L288	Under Floor Light Bulb	O_UdrFirLb	A46	J1:20	25.1
L18-L19-L211	Entrance Door Step Light Bulb	O_EntDorStpLb	A47	J1:5	29.1
L203	Driver Recycle Trap	O_DrvRecTrap	A47	J1:2	18.1
L205	A/C Pass. Gaz Cylinder Recycle	O_ACRecPass	A54	J1:20	18.2
L21-L22-L23-L24-L25-L26-L27	Front Clearance Lights Bulb	O_FrClearLb	A44	J1:8	26.1
L59	Right Hand Hi Beam Light Bulb	O_RHHiBeamLb	A48	J1:3	26.1
L59	Right Hand Low Beam Light Bulb	O_RHLwBeamLb	A48	J1:4	26.1
L60	Left Hand Hi Beam Light Bulb	O_LHHiBmLb	A45	J1:6	26.1
L60	Left Hand Low Beam Light Bulb	O_LHLwBmLb	A45	J1:7	26.1
L61	Right Hand Front Flasher Light Bulb	O_RHFrFishLb	A48	J1:6	26.1
L61	Right Hand Front Markers Light Bulb	O_RHFrMrkLb	A48	J1:7	26.1
L62-L65	Left Hand Front Markers Light Bulb	O_LHFrMkrLb	A45	J1:21	26.1
L62-L66	Left Hand Front Flasher Light Bulb	O_LHFrFishLb	A45	J1:3	26.1
L64	RH Front Side Flasher L-Bulb	O_RHFrSidFishLb	A48	J1:20	26.1
L95	Left Hand Fog Light Bulb	O_LHFogLb	A45	J1:4	26.3
L95	Right Hand Fog Light	O_RHFogLb	A48	J1:8	26.3
L97	Left Hand Cornering Light Bulb	O_LHCornerLb	A45	J1:5	26.3
L98	Right Hand Cornering Light Bulb	O_RHCornerLb	A48	J1:5	26.3
Mo12	Hvac Water Pump	O_ACWaterPmp	A54	J1:4	18.2
Mo19-Mo20	Lower Wiper Washer Pump	O_LwWshPmp	A46	J1:3	31.1
Mo26	Entrance door lock motor	O_DoorLockMo	A48	J1:2	29.1
Mo26	Entrance door unlock motor	O_DoorUnlockMo	A48	J1:1	29.1
Mo3	Dash Trap Motor Return	O_DashTrapNMo	A44	J1:2	18.1
Mo3	Dash Trap Motor	O_DashTrapPMo	A44	J1:1	18.1

MULTIPLEX DEVICES LIST

Device ID	Description	Name	Module ID	Module Pin#	Page
Mo4A	Foot Trap Solenoid	O_FootTrpPSol	A45	J1:1	18.1
Mo4B	Foot Trap Solenoid	O_FootTrpNSol	A45	J1:2	18.1
Mo50	Auxiliary water pump	O_AuxWaterPump	A47	J1:20	18.1
Mo53	Hvac Passenger Heat Led	O_RJBFanMo	A46	J1:7	11.1
Mo9	Evaporator Fan Speed 2	O_EvaSpd2Rel	A54	J1:2	18.2
Pot1	Dash BackLighting	O_DashBackLit	A44	J1:20	19.1
R1		O_MasterRlyLatch	A36	JA:14	
R10	Condensor Fan Speed 1 Relay	O_CndSpd1Rel	A54	J1:5	18.2
R12	Evaporator Fan Speed 1 Relay	O_EvaSpd1Rel	A54	J1:7	18.2
R16	Flasher Audible Relay	O_FlshAudiRel	A45	J1:8	26.1
R17-R18-R19	WakeUp Relay	O_WakeUp	A36	JA:15	3.3
R21	Emergency CutOut Relay	O_CutOutRel	A36	JA:24	3.2
R23	Lower Wiper Speed 1	O_LwWipSpd1	A47	J1:3	31.1
R30-R31	Luggages doors locks relays	O_DrLockRly	A36	JA:7	24.2
R32-R33	Luggages doors unlocks relays	O_DrUnlockRly	A36	JA:6	24.2
R9	Condensor Fan Speed 2 Relay	O_CndSpd2Rel	A54	J1:1	18.2
Se17	Entrance Door Open Sensor	I_EntDorOpSe	A41	J1:5	29.1
Se18	Paking Brake Sensor	I_ParkBrSe	A36	JB:9	12.1
Se19	Brake Lights Sensor	I_BrkLtSeFrSig	A36	JB:13	12.1
Se21	Driver Temperature sensor	I_DrvTempSe	A46	J1:13	18.1
Se25	Passenger temperature sensor	I_PassTempSe	A54	J1:13	18.2
Se45		I_WipWshLowLvl	A42	J1:17	31.1
Se46		I_TrailerPrkBkSe	A42	J1:1	12.1
Se52	Coil sensing thermostat	I_CoilTherSe	A47	J1:11	18.1
So11	Passenger Refrigerent Solenoid	O_PasRfgSol	A54	J1:3	18.2
So13	Passenger Heat Solenoid Valve	O_PasHeatSol	A54	J1:8	18.2
So7	Driver refrigerent solenoid	O_DrvRfgSol	A46	J1:5	18.1
So8	Driver Heat Solenoid	O_DrvHeatSol	A46	J1:6	18.1
Sw1	Lower Wiper Intermitant Switch	I_LwWipIntSw	A42	J1:8	31.1
Sw1	Courtesy Blink Switch	I_BlinkSw	A43	J1:20	26.1
Sw1	Head Lights High and Low Beam Switch	I_HdLthiLowBmSw	A43	J1:8	26.1
Sw1	Left Hand Flasher Switch	I_LHFishSw	A45	J1:9	26.1
Sw1	Lower Wiper Washer Switch	I_LwWshSw	A46	J1:9	31.1
Sw1	Right Hand Flasher Switch	I_RHFishSw	A48	J1:12	26.1
Sw102	Low docking lights switch	I_LowDockLtsSw	A43	J1:5	26.3
Sw103	Reverse alarm switch	I_RevAlrmSw	A43	J1:6	26.3
Sw104	VIP Entrance Door Lock Switch	I_EntDorLockSw	A41	J1:9	29.1
Sw104	Entrance door unlock switch	I_EntDrUnlockSw	A41	J1:8	29.1
Sw104	Entrance door unlock switch	I_EntDrUnSw	A48	J1:9	29.1
Sw119	Back up camera switch	I_BackUpCamSw	A42	J1:6	
Sw122	Passenger defrost speed increase switch	I_DefrostHighSw	A47	J1:10	18.1
Sw122	Passenger defrost speed decrease switch	I_DefrostLowSw	A47	J1:12	18.1
Sw13		I_InoutTest	A36	JB:11	9.1

MULTIPLEX DEVICES LIST

Device ID	Description	Name	Module ID	Module Pin#	Page
Sw14	Fast Idle Switch	I_FastIdleSw	A44	J1:11	14.1
Sw18	Luggage Door Lock Switch	I_LugDorLkSw	A41	J1:17	24.2
Sw18	Luggage Door Unlock Switch	I_LugDorULkSw	A41	J1:20	24.2
Sw2	Head Light Switch Position Markers	I_HdLtPos1Sw	A43	J1:4	26.1
Sw2	Hi/Low Beam Switch	I_HiBeamCallSw	A43	J1:3	26.1
Sw2	Head Light Switch Beam Position 2 LH	I_HdLtPos2SwLH	A45	J1:12	26.1
Sw2	Head Light Switch Beam Position 2 RH	I_HdLtPos2SwRH	A48	J1:10	26.1
Sw22	Radiator Fan Switch	I_EngFanSw	A36	JB:14	13.1
Sw22		I_EngFanSw2	A36	JB:1	
Sw23	Ether Switch	I_EtherSw	A42	J1:5	13.1
Sw24	Driver Light Switch	I_DrvLtSw	A41	J1:2	19.1
Sw3	Fog Lights Switch	I_FogLightSw	A43	J1:10	26.3
Sw35	Cruise Control Enable Switch	I_CruiseEnSw	A42	J1:3	14.1
Sw4	Hazard Switch	I_HazardSw	A36	JB:4	26.1
Sw40		I_TrailerPrkBkSw	A42	J1:4	12.1
Sw44	Front Junction Box Door Open	I_FJBLtSw	A43	J1:17	25.1
Sw82	Rear Junction Box CutOut Switch	I_RrCutOutSw	A36	JB:21	3.2
Sw83	Accessories Key switch	I_AccKeySw	A36	JB:6	3.2
Sw83	Front Engine Start Switch	I_FrEngStaSw	A36	JB:22	3.2
Sw83	Ignition Key switch	I_IgnKeySw	A36	JB:2	3.2
Sw99	Cornering Light Switch	I_CorneringLtSw	A43	J1:21	26.3
Sw99	Docking Lights Switch	I_DockingLtSw	A43	J1:7	26.3
		I_BatMonMod41	A41	J1:24	6.1
		I_BatMonMod42	A42	J1:24	6.1
		I_HeadLmpWshSw	A42	J1:18	31.1
		I_BatMonMod43	A43	J1:24	6.1
		I_BatMonMod44	A44	J1:24	6.1
		I_BatMonMod45	A45	J1:24	6.1
		I_BatMonMod46	A46	J1:24	6.1
		O_HeadLmpWshMo	A46	J1:21	31.1
		I_BatMonMod47	A47	J1:24	6.1
		I_BatMonMod48	A48	J1:24	6.1
		I_BatMonMod54	A54	J1:24	6.1