

DIODES LIST

No	Location	Part #	Function	Page
D1	FJB	561740	AccessoriesDiode	3.2
D2	FJB	561740	DiodeDriverLiq.Sol.	18.1
D4	RHConsole	561740	SuppressorDiodeLowerWiper2ndSpd	31.1
D5	RHConsole	561740	SuppressorDiodeLowerWiper1stSpd	31.1
D6	RJB	561740	SuppressorDiodeMasterrelay	3.1
D11	Evap.Cmpt.	561740	DiodePass.Liq.Sol	18.2
D12	RJBVECR	561740	*opt*	12.1
D15	RJB	561740	WakeUpDiode	3.2
D22	RJBVECR	561740	ServiceBrakeDiode	12.1
D25	Evap.Cmpt.	561740	SuppressorDiodeEvaporatorFan	18.2
D28	RJB	561740	SuppressorDiodeUnloaderLH	18.2
D29	RJB	561740	SuppressorDiodeUnloaderRH	18.2
D30	Evap.Cmpt.	561740	SuppressorDiodeWaterPump	18.2
D31	RJB	561740	SuppressorDiodeA/Cclutch	18.2
D32	LHConsole	563374	*opt*	30.1
D33	LHConsole	563374	*opt*	30.1
D36	RJB	561740	SuppressorDiodeRadiatorFanClutch2ndSpd	13.1
D37	RJB	561740	SuppressorDiodeRadiatorFanClutch1stSpd	13.1
D38	FrontCeiling	563375	SuppressorZenerDiodeSunVisorRH	30.1
D39	FrontCeiling	563375	SuppressorZenerDiodeSunVisorRH	30.1
D40	UpperFrontCap	563375	SuppressorZenerDiodeSunVisorLH	30.1
D41	UpperFrontCap	563375	SuppressorZenerDiodeSunVisorLH	30.1
D42	LHConsole	563374	SuppressorZenerDiodeDriverWdw	30.1
D43	LHConsole	563374	SuppressorZenerDiodeDriverWdw	30.1
D44	FJB	561740	IgnitionDiode	3.2
D45		561740	Diodesuppressor	9.1
D46	RJBVECR	561740	Diode	12.1
D50		561740	*opt*	28.1
D51		561740	*opt*	28.1
D56	Evap.Cmpt.	561740	*opt*	29.1
D66	ServiceCmpt.	561740	SuppressorDiodeWaterPump	18.1
D67		561740	*opt*	26.2
D68		561740	*opt*	26.2
D69		561740	*opt*	26.2
D70		561740	*opt*	26.2
D71	LHConsole	563374	*opt*	29.1
D72	LHConsole	563374	*opt*	29.1
D73	Evap.Cmpt.	561740	*opt*	29.1
D75		561740	ParkBrakeDiode	20.1
DSO1		563375		20.1
DSO2		563375	*opt*	20.1
DSO3		*opt*	*opt*	20.1
DSO4		*opt*	*opt*	20.1