

RESISTORS LIST

No	Location	Part #	Function	Page					
Res3	RJB	563593	TerminaisonResistor	6.1					
Res4	RJB	563593	TerminaisonResistor	6.1					
Res6	FJB	563593	TerminaisonResistor	6.1					
Res7	FJB	563593	TerminaisonResistor	6.2					
Res9	Dash	564164	Dimmer_Resistor	19.1					
Res15	EngineCmpt.	563587	ENDOFLINEDEVICE	35.1					
Res16	RJB	563006	CurrentLimitResistor	26.2					
Res17	RJB	563006	CurrentLimitResistor	26.2					
Res18	RearRoof	563593	TerminaisonResistor	14.5					
Res31	Cond.Cmpt.	NA	UreaHoseHeater	14.5					
Res32	Cond.Cmpt.	NA	Urea_Hose_Heater	14.5					
Res33	FJB	561534	Cluster_Switch_Select	10.1					
Res34	FJB	561534	Cluster_Switch_Escape	10.1					
Res35	FJB	561534	Cluster_Switch_Up	10.1					
Res36	FJB	561534	Cluster_Switch_Down	10.1					
Res53	FJB	563593	TerminaisonResistor	6.2					