

CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
A 1	UNDER DASH – AUDIO SIGNAL	RCA	1	562090	562330	C 58					
A 2	UNDER DASH – AUDIO SIGNAL	RCA	1	562090	562330	C 59					
A 10	UNDER DASH – AUDIO SIGNAL	RCA	1	562090	562330	C 60					
A 11	UNDER DASH – AUDIO SIGNAL	RCA	1	562090	562330	C 61	ENGINE COMPT - FUEL FILTER	PED WP	2	561566	561690
A 18	S. S. PANEL – AUDIO SIGNAL	RCA	1	562090	562330	C 62	ENGINE COMPT – COMPR. AUX. PRESS. SW.	PED WP	2	561566	561690
A 19	S. S. PANEL – AUDIO SIGNAL	RCA	1	562090	562330	C 63	ENGINE COMPT – COMPR. AUX. PRESS. SW.	PED WP	2	561566	561690
AA 1	UNDER DASH PANEL- SONALERT	BOSCH	5	-----	561183	C 64					
C 1	FR JCT BOX COMPARTIMENT	AMP CPC	14	561585	561584	C 65	ENGINE CPT – A/C PRESS SW FAN CLUTCH	PED WP	2	561566	561690
C 2	FR JCT BOX COMPARTIMENT	AMP CPC	16	561639	561640	C 66					
C 3	FR JCT BOX COMPARTIMENT	AMP CPC	37	561644	561646	C 67					
C 4	FR JCT BOX COMPARTIMENT	AMP CPC	24	561641	561643	C 68					
C 5	FR SERVICE COMPT. - UNDERNEATH	AMP CPC	37	561645	561646	C 69					
C 6	FR SERVICE COMPT. - UNDERNEATH	AMP CPC	16	561639	561640	C 70	LH CONSOLE	AMP CPC	16	561639	561640
C 7	FR SERVICE COMPT - CLUTCH SW	ITT SS	3	561080	561111	C 71	FR JCT BOX COMPT.	AMP CPC	37	561645	561646
C 8	FR SERVICE COMPT. - UNDERNEATH	AMP CPC	24	561642	561643	C 72	FR JCT BOX COMPT.	AMP CPC	24	561642	561643
C 9	FR SERVICE COMPT. - UNDERNEATH	AMP CPC	24	561642	561643	C 73					
C 10	FR SERVICE DOOR ACCESS.	DEUTSCH	5	562565	562566	C 74	FR JCT BOX COMPT.	AMP CPC	37	561645	561646
C 11	FR SERV. CPT ACCESS	AMP CPC	37	561645	561646	C 75					
C 12	FR SERV. CPT ACCESS	AMP CPC	16	561639	561640	C 76	ENGINE CMPT. FIRE DETECTOR	DEUTSCH	2	562486	562485
C 13						C 77	ENGINE CMPT. FIRE DETECTOR	DEUTSCH	2	562486	562485
C 14						C 78					
C 15						C 79					
C 16	LH CONSOLE SW-CRUISE ON/OFF	EATON	12	-----	562763	C 80					
C 17	LH CONSOLE SW-CRUISE RESUME	EATON	12		562763	C 81	LUGGAGE COMPT - DOOR LOCK	AMP MNL	4	560851	560852
C 18	LH CONSOLE SW-CRUISE SET	EATON	12		562763	C 82	UNDER SEAT – AISLE LTS	AMP MNL	2	560900	560858
C 19	LH CONSOLE SW-DECEL SW	EATON	12		562763	C 82	LUGGAGE COMPT - DOOR LOCK	AMP MNL	4	560851	560852
C 20	RR JCT BOX	DEUTSCH	70	562282	562285	C 83	LUGGAGE COMPT - DOOR LOCK	AMP MNL	4	560851	560852
C 21	ENGINE COMPT - LOCK DOOR MOT.	PED WP	2		562076	C 84	LUGGAGE COMPT - DOOR LOCK	AMP MNL	4	560851	560852
C 22	LUGGAGE COMPT (A) - A/C & FUEL TANK	AMP CPC	16	561639	561640	C 85					
C 23	LUGGAGE COMPT (1) – LUGG. ACCESS.	AMP CPC	24	561642	561643	C 86					
C 24	ENGINE COMPT. – INTERF RJB	PED WP	6	561606	561607	C 87					
C 25	ENGINE COMPT. – INTERF RJB	PED WP	6	561606	561607	C 88					
C 26	ENGINE COMPT. ACCESS	DEUTSCH	40	562281	562284	C 89					
C 27	ENGINE COMPT. – INTERF. RJB	DEUTSCH	6	562583	562581	C 90					
C 28	LUGGAGE COMPT(4) – LUGG. ACCESS	AMP CPC	24	561642	561643	C 91					
C 29	FR SERVICE COMPT – E.C.U. FEED	PED WP	3	561781	561782	C 92	FR JCT BOX COMPT - ABS	AMP CPC	9	561635	561637
C 30	ENGINE COMPT – MASTER SW. SIGN.	DEUTSCH	2	562486	562485	C 93					
C 31	RR JCT BOX – PARCEL RACK FEEDING	DEUTSCH	31	562572	562536	C 94					
C 32						C 95					
C 33	FR SERV. COMPT. – VSS SIGNAL	PED WP	2	561566	561690	C 96	FR SERVICE DOOR ACCESS	AMP MNL	9	561670	561669
C 34						C 97	FR SERVICE DOOR – WATER TANK	PED MP	2		562426
C 35	A/C COMPT - AIR RETURN SENSOR	AMP MNL	2	561248	561247	C 98					
C 36	UNDER STAIRS – STEP LIGHTS	AMP MNL	2	561248	561247	C 99	FR SERVICE CPT. LTS	AMP MNL	2	561248	561247
C 37	RH PARCEL RACK – EMERGENCY LTS	AMP MNL	2	560900	560898	C 100					
C 38	LH PARCEL RACK - FEEDING	MOLEX	6	562558	562557	C 101	FR SERVICE COMPT. ELEC. HORNS	PED WP	2	561566	561690
C 39	RH PARCEL RACK - FEEDING	MOLEX	6	562558	562557	C 101	CONDENSER COMPT - A/C PRES. SW 1SP	PED WP	2	561566	561690
C 40						C 102	CONDENS. COMPT – LIQU. SOL. VAL. PRES.	PED WP	2	561566	561690
C 41	ENGINE COMPT – RH DOOR LOCK	DEUTSCH	4	562479	562477	C 103	ENGINE COMPT. – LAVATORY FAN	PED WP	2	561566	561690
C 42	ENGINE COMPT – RR CAP LIGHTING	DEUTSCH	6	562583	562581	C 104	ENGINE COMPT. – LAVATORY PUMP	DEUTSCH	2	562486	562485
C 43	FR JCT BOX – ALT. MODULE	AMP MNL	12	561735	561734	C 105	UNDER DASH RH - DRV LIO SOL VL	PED WP	2	561566	561690
C 44	ENGINE COMPT - LIGHTS	PED WP	1	561605	561577	C 106	UNDER DASH RH - DRV WTR VALVE	PED WP	2	561566	561690
C 45	FR JCT BOX COMPT – ROOF ACCESS	AMP CPC	24	561642	561643	C 107					
C 46						C 108					
C 47						C 109					
C 48	FR SERV. CPT. PRESS SW PARK BRAKE	DEUTSCH	4	562479	562477	C 110					
C 49	LAVATORY ROOF – NIGHT LIGHT	AMP MNL	2	560900	560858	C 111					
C 50						C 112					
C 51						C 113					
C 52	ENGINE COMPT - COMPRESSOR	PED WP	2	561566	561690	C 114	ENGINE DDEC - SPEED SIGNAL	PED WP	2	561566	561690
C 53	ENGINE COMPT - COMPRESSOR	PED WP	2	561566	561690	C 115	RR JCT BOX – ENGINE ACCESS	DEUTSCH	40	562281	562284
C 54						C 116	DRIVE AXLE COMPT - AIR DRYER	PED MP	2		562251
C 55	CENTRAL DOOR LOCK	DEUTSCH	4	562479	562477	C 117					
C 56	LH PARCEL RACK - FEEDING	MOLEX	6	562558	562557	C 118	ENGINE COMPT - LICENCE	DOM. AUT	2	930210	
C 57	RH PARCEL RACK - FEEDING	MOLEX	6	562558	562557	C 119	ENGINE COMPT - RH LOWER LAMP	PED WP	6	561606	561607
						C 120	ENGINE COMPT - LH LOWER LAMP	PED WP	6	561606	561607

CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
C 121						C 184	FR SERV. COMPT. - KNEELING PROX. SW.	ITT SS	3	561080	561111
C 122						C 185	KNEELING PANEL - DOWN SOL. VALVE	PNEUMAC	3		641385
C 123						C 186					
C 124						C 187	FR SERVICE JCT BOX - RESISTORS	AMP MNL	6	561552	561515
C 125						C 187	KNEELING PANEL- PARK BRAKE INTERLOCK	PNEUMAC	3		641385
C 126						C 188					
C 127						C 189					
C 128						C 190					
C 129						C 191					
C 130						C 192					
C 131						C 193					
C 132						C 194					
C 133						C 195					
C 134	FR JCT BOX - DIODE CONN.	AMP MNL	15	561987	561986	C 196	KNEELING PANEL - UP SOL. VALVE	PNEUMAC	3		641385
C 135	FR JCT BOX - DIODE CONN.	AMP MNL	15	561987	561986	C 197	KNEELING PANEL - CTR SOL. VALVE	PNEUMAC	3		641385
C 136	FR JCT BOX - DIODE CONN.	AMP MNL	15	561987	561986	C 198					
C 137						C 199					
C 138						C 200	PARCEL RACK - FLUORESCENT LTS	AMP MNL	2	561248	561247
C 139						C 201	PARCEL RACK - FLUORESCENT LTS	AMP MNL	2	561248	561247
C 140	HVAC DASH MODULE THERMOMETER	MOLEX	4		562782	C 202	RH PARCEL RACK - INDIRECT LTS	MOLEX	2		562758
C 141	RR DASH PANEL - LTS CONN. (SPARE)	AMP MNL	2	561248	561247	C 203	PARCEL RACK - FLUORESCENT LTS	MOLEX	6		562759
C 142	ENGINE COMPT. B/U ALARM	PED WP	2	561566	561690	C 204	RH PARCEL RACK - RACK LTS	AMP MNL	2	560900	560858
C 143						C 205	RH PARCEL RACK - FEEDING	AMP MNL	9	561661	561662
C 144	FR JCT BOX - AISLE LTS FEEDING	AMP MNL	2	561248	561247	C 206	RH PARCEL RACK - FEEDING	AMP FF	4	562760	562756
C 145						C 207	LH PARCEL RACK - FEEDING	AMP FF	4	562760	562756
C 146						C 208	PARCEL RACK - FLUORESCENT LTS	MOLEX	2		562758
C 147						C 209	LH PARCEL RACK - HOTESS CHIME	AMP MNL	3	561667	561550
C 148						C 210	LH PARCEL RACK - FEEDING	AMP MNL	9	561661	561662
C 149						C 211	FR ROOF - SUN VISOR LH	AMP MNL	2	560900	560898
C 150						C 212	FR ROOF - SUN VISOR RH	AMP MNL	2	560900	560898
C 151						C 213					
C 152						C 214					
C 153						C 215					
C 154						C 216					
C 155						C 217	RH PANEL SW. - SCENIC VIEW CAMERA	EATON	12		562763
C 156						C 218	RH PANEL SW. - LIGHTS SPARE	AMP MNL	2	560900	560898
C 157	FR SERV. CPT - WATER PUMP DR'S	PED WP	3	561781	561782	C 219					
C 158						C 220					
C 159						C 221					
C 160	FR SERVICE CPT - INTERFACE	AMP CPC	37	561644	561646	C 222					
C 161	ENGINE DDEC - ECM	PED MP	30		561600	C 223	HEAD LIGHTS - FLASHER	DEUTSCH	5	562565	562566
C 162	ENGINE DDEC - ACCESSORIES	PED WP	4	561610	561611	C 224	HEAD LIGHTS	PED MP	3		562099
C 163	ENGINE CPT - COOLANT PROBE	PED MP	2		562350	C 225	FOG LIGHTS	DEUTSCH	3	562902	562901
C 164						C 226	FRONT HEADLIGHTS - MARKER & FLASHER	PED	3	562137	
C 165						C 226	BATT. COMPT. - INTERIOR LTS	AMP MNL	2	561248	561247
C 166						C 227					
C 167	FR SERVICE CPT - EL. FOOT PEDAL	PED WP	3	561781	561782	C 228					
C 168	FR SERVICE CPT - DDR	DEUTSCH	6		562360	C 229					
C 169	FR SERVICE CPT - WORLD TR. INTERFACE	AMP CPC	16	561639	561640	C 230	ENGINE COMPT. - FUEL PRIME PUMP SW.	PED WP	2	561566	561690
C 169	FR SERV. COMPT. - SPEED SWITCH	AMP	15	562011	562012	C 231	ENGINE COMPT. - FUEL PRIME PUMP	PED WP	2	561566	561690
C 170	FR JCT BOX FLASHER UNIT	PED	2		561940	C 232					
C 171	LH CONSOLE	AMP CPC	24	561642	561643	C 233					
C 172	FR SERVICE COMPT - KNEELING PANEL	AMP CPC	16	561639	561640	C 234					
C 172	ENGINE COMPT. - WATER TANK HEATER	PED WP	2	561566	561690	C 235					
C 173						C 236	FR SERVICE CPT CENTER - ABS	AMP CPC	14	561636	561637
C 174						C 237	FR AXLE CPT - ABS RH SENSOR	WABCO	2	641132	
C 175						C 238	FR AXLE CPT - ABS RH VALVE	WABCO	3	641098	
C 176	UNDER DASH RH - WIPER PULSE	AMP FF	6		561186	C 239	FR AXLE CPT - ABS LH VALVE	WABCO	3	641098	
C 177	UNDER DASH RH - WIPER MOTOR	AMP FF	6		561186	C 240	FR AXLE CPT - ABS LH SENSOR	WABCO	2	641132	
C 178						C 241	LAST LUGGAGE COMPT - ABS	PED WP	6	561606	561607
C 179						C 242	DRIVE AXLE CPT - ABS LH SENSOR	WABCO	2	641132	
C 180	KNEELING PANEL - DIODE SOCKET	AMP MNL	15	561987	561986	C 243	DRIVE AXLE CPT - ABS LH VALVE	WABCO	3	641098	
C 181						C 244	DRIVE AXLE CPT - ABS RH VALVE	WABCO	3	641098	
C 182						C 245	DRIVE AXLE CPT - ABS RH SENSOR	WABCO	2	641132	
C 183						C 246	DRIVE AXLE CPT - ATC SOL.	PED WP	2	561566	561690

CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
C 247						C 310	LH CONSOLE SW – LUG. DOOR LOCK	EATON	12		562763
C 248	LAST LUGGAGE CPT - ABS	PED WP	6	561606	561607	C 311	RH SWITCH PANEL – HOTESS CHIME	EATON	12		562763
C 249	FR SERVICE CPT - ABS/DDEC	PED WP	2	561566	561690	C 312	ENGINE DDEC - ACCESSORIES	PED WP	3	561781	561782
C 250						C 312	RH SWITCH PANEL – READING LAMP	EATON	12		562763
C 251	LH SW PANEL – FAST IDLE	EATON	12		562763	C 313	ENGINE DDEC – INTERFACE	PED MP	3	562398	
C 252	LUGGAGE COMPT. – WINDOW AJAR	MOLEX	4	561477	561476	C 313	RH SWITCH PANEL – INTERIOR LTS	EATON	12		562763
C 253	LH SWITCH PANEL - ETHER	EATON	12		562763	C 314	KNEELING PANEL – PRESS SW.	PED WP	2	561566	561690
C 254						C 314	RH SWITCH PANEL – INTERIOR LTS	EATON	12		562763
C 255	LH SWITCH PANEL – ENGINE BRAKE	EATON	12		562763	C 315	LH SWITCH PANEL – LH SUN VISOR SW.	EATON	12		562763
C 256						C 316	RH UNDER DASH – KNEELING BUZZER	AMP MNL	2	560900	560898
C 257	ENGINE COMPT - WATER HEATER	AMP FF	6		561186	C 317	LH SWITCH PANEL – RH SUN VISOR SW.	EATON	12		562763
C 258	LH SWITCH PANEL – MULTI FUNC. SW	AMP FF	8	561188		C 318	LH CONSOLE SW – DR'S WINDOW SW.	EATON	12		562763
C 259	ENGINE COMPT. – WATER HEATER	PED	2	562644	561597	C 319					
C 259	LH SWITCH PANEL – MULTI FUNC. SW	AMP FF	6		561186	C 320	RT SWITCH PANEL – DRIVER'S LTS SW.	EATON	12		562763
C 260	ENGINE COMPT - WATER HEATER	AMP FF	2	562473	562474	C 321	UNDER DASH RH - KEYLESS MODULE	AMP COM	26		562676
C 261	ENGINE COMPT - WATER HEATER	PED	2	562644	561597	C 322	UNDER DASH RH - KEYLESS MODULE	AMP COM	22		562675
C 262						C 323	DRIVER'S WINDOW MOTOR	PED	2		561848
C 263	LUGGAGE COMPT. LTS COMPT #3	AMP MNL	2	561248	561247	C 324					
C 264	LUGGAGE COMPT. LTS COMPT #2	AMP MNL	2	561248	561247	C 325	LH SWITCH PANEL – KNEELING	EATON	12		562763
C 265	LUGGAGE COMPT. LTS COMPT #1	AMP MNL	2	561248	561247	C 326	EATON TRANSMISSION INTERFACE	PED WP	4	561610	561611
C 266	ENTRACE DOOR KEYLESS	AMP CPC	14	561585	561583	C 327					
C 267	UNDER DASH RH – ENT. DOOR PANEL	AMP CPC	24	561642	561643	C 328	RR ROOF – GALLEY LAMP		2		
C 268	FR MIRROR RH	SW. CRAF	5	562921		C 329					
C 269	FR MIRROR LH	SW. CRAF	5	562921		C 330					
C 270	LUGGAGE COMPT LTS - 3 LH	AMP MNL	2	561248	561247	C 331					
C 271	LUGGAGE COMPT LTS - 4	AMP MNL	2	561248	561247	C 332					
C 272						C 333					
C 273	ENT. DOOR PANEL – DIODE SOCKET	AMP MNL	9	561670	561669	C 334					
C 274						C 335					
C 275	ENT. DOOR PANEL – DIODE SOCKET	AMP MNL	9	561670	561669	C 336					
C 276						C 337					
C 277	RH UNDER DASH – ENT. DOOR REED SW.	AMP MNL	2	560900	560858	C 338					
C 278	RH PASS. AIR DUCT – ENT DOOR PRESS SW.	PED WP	2	561566	561690	C 339	KNEELING PANEL – HI BUOY SOL. VALVE	PNEUMAC	3		641385
C 279	RH UNDER DASH – ENT. DOOR REED SW.	AMP MNL	2	560900	560858	C 340	FR JCT BOX – FIRE PIEZO ALARM	AMP MNL	2	560900	560898
C 279	FR SERVICE COMPT LH – STEERING ZF	DEUTSCH	2		562485	C 341	LH SWITCH PANEL – HEAT MIRROR SW.	EATON	12		562763
C 280	ENGINE COMPT – A/C COMPRESSOR AUX.	PED WP	2	561566	561690	C 342					
C 281						C 343	LH SWITCH PANEL – HEAD LAMP SW.	EATON	12		562763
C 282	FR SERVICE COMPT – STEERING ZF	VOLVO	2		562928	C 344	LH SWITCH PANEL – HAZARD LT SW.	EATON	12		562763
C 283	LH CONSOLE – SPARE SW. LTS	AMP MNL	2	561248	561247	C 345	LH SWITCH PANEL – FOG LT SW.	EATON	12		562763
C 284						C 346					
C 285						C 347					
C 286						C 348	INSTR. PANEL CENT. – RACOR MODULE	MOLEX	6	562070	562069
C 287						C 349					
C 288						C 350					
C 289						C 351					
C 290	LUGGAGE CPT - DOOR LOCK	AMP MNL	4	560851	560852	C 352					
C 291	LUGGAGE CPT - DOOR LOCK	AMP MNL	4	560851	560852	C 353					
C 292						C 354					
C 293						C 355					
C 294						C 356					
C 295						C 357					
C 296						C 358					
C 297						C 359	RH SWITCH PANEL – ENT. DOOR WIND. SW.	EATON	12		562763
C 298						C 360	ENTRACE WINDOW MOTOR	PED	2		561848
C 299	RH SWITCH PANEL - GALLEY	EATON	12		562763	C 361					
C 300						C 362					
C 301						C 363					
C 302						C 364	FRONT ROOF - ELECTRICAL DEST. SIGN	AMP MNL	3	561667	561550
C 303	RR JCT BOX - DIODES	AMP MNL	15	561987	561986	C 365					
C 304	RR JCT BOX - DIODES	AMP MNL	15	561987	561986	C 366					
C 305						C 367					
C 306						C 368	FRONT ROOF – ELECTRICAL DEST. SIGN	AMP MNL	3	561667	561550
C 307						C 369	FRONT ROOF – ELECTRICAL DEST. SIGN	TORRIX	5	562110	
C 308						C 370	FRONT ROOF – ELECTRICAL DEST. SIGN	AMP MNL	2	560900	560858
C 309	ENGINE DDEC - ECM POWER	PED MP	5		562345	C 371	FRONT ROOF – ELECTRICAL DEST. SIGN	AMP MNL	3	561667	561550

CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
C 372	FRONT ROOF – ELECTRICAL DEST. SIGN	MOLEX	4	561477	561476	C 437					
C 373						C 438					
C 374						C 439					
C 375						C 440					
C 376						C 441					
C 377	LH SWITCH PANEL – STOP ENGINE OVERRIDE	EATON	12		562763	C 442					
C 378						C 443					
C 379	LUGGAGE COMPT. – WINDOW AJAR SW.	MOLEX	4	561477	561476	C 444					
C 380						C 445					
C 381	UNDER DASH PANEL – ANTI THILED	AMP MNL	2	561248	561247	C 446					
C 382	ENGINE GENERATOR (1)	PED WP	1	561605	561577	C 447					
C 383	ENGINE COMPT – VOLTAGE REGULATOR	PED WP	1	561605	561577	C 448					
C 384						C 449					
C 385	BATT. COMPT. – BJB INTERFACE	AMP MNL	12	561735	561736	C 450	S.S. PANEL - FEEDING	MOLEX	4	562507	562503
C 386	LH SWITCH PANEL – W.C.LIFT	EATON	12		562763	C 451	S.S. PANEL - FEEDING	MOLEX	2	562550	562549
C 387	EVAPORATOR COMPT. - BY-PASS VALVE	PED WP	2	561566	561690	C 452	UNDER DASH – S.S. ACC. SIGNAL	MOLEX	2	562550	562549
C 388						C 453	S. S. PANEL – VCR FEEDING	PED WP	2	561566	561690
C 389	EVAPORATOR COMPT. – WATER PUMP	PED WP	2	561566	561690	C 454	S. S. PANEL – VCR FEEDING	PED WP	2	561566	561690
C 390	EVAPORATOR COMPT. – A/C JCT. BOX	DEUTSCH	24	562280	562283	C 455	PARCEL RACK – WIRELESS MICROPHONE	MOLEX	6		562464
C 391	CONDENSER COMPT. A/C PRESS SW 2 SP	PED WP	2	561566	561690	C 456	WORLD TRANS. - RETARDER ACCUM.	PED MP	2		562427
C 392						C 457	WORLD TRANS. - MAIN CONNECTOR	DEUTSCH	31	562572	562536
C 393						C 458	WORLD TRANS. - TURBINE SP. SENS.	PED MP	2		562426
C 394	UNDER DASH - B/U MONITOR	AMP MNL	4	560851	560852	C 459	WORLD TRANS. - ENGINE SP. SENS.	PED MP	2		562426
C 395	UNDER DASH - B/U MONITOR	CLARION	4		990335	C 460	WORLD TRANS. - SPEED SENSOR	ITT	2		562541
C 396	PARCEL RACK – SPEAKER FEEDING	MOLEX	4	562507	562503	C 461	WORLD TRANS. - RETARDER TEMP.	PED MP	2		562856
C 397						C 462	WORLD TRANS. - RETARDER SOL. "K"	PED MP	2		562426
C 398						C 463	WORLD TRANS. - SENSOR CONN.	DEUTSCH	16	562570	562571
C 399	ENGINE GENERATOR (2)	PED WP	2	561566	561690	C 464	RR JCT BOX - DDL CONN	DEUTSCH	6		565360
C 400	ENGINE COMPT. – BLOCK HEATER	PED WP	3	561781	561782	C 465	LH CONSOLE - SHIFTER SELECTOR	PED	20		562825
C 401						C 466	FR SERVICE CPT - RESIS. MOD.	PED WP	3		562428
C 402						C 467	FR SERVICE CPT - RESIS. MOD.	PED WP	3		562428
C 403	GALLEY – REFRIGERATOR		2			C 468	STEERING COLUMN – RET. HAND LEVER	AMP FF	8	561188	562363
C 404	GALLEY – LAMP SWITCH		2			C 469	FR SERVICE COMPT. – RESIS. MOD.	AMP FF	8	561188	562363
C 405						C 470					
C 406						C 471					
C 407						C 472	FR SERVICE CPT – SILENT 1000	PED WP	2	561566	561690
C 408						C 473					
C 409						C 474	DRIVER'S TEMP SENSOR	AMP MNL	2	561248	561247
C 410						C 475	FR SERVICE CPT - SPEED SIGN. CONNECT.	DEUTSCH	6	562583	562581
C 411						C 475M	FR SERVICE CPT – SPEED SIGN. W. TR.	DEUTSCH	6	562583	562581
C 412						C 475W	FR SERVICE CPT – SPEED SIGN. W. TR.	DEUTSCH	6	562583	562581
C 413						C 476					
C 414						C 477					
C 415						C 478	FRONT ROOF – ELECTRONIC DEST. SIGN	AMP CPC	9	561636	561637
C 416						C 479	UNDER DASH – HVAC DASH MODULE	MOLEX	3		562783
C 417						C 480	UNDER DASH RH – DR'S FAN SPEED CTR	PED WP	4	561889	561890
C 418						C 481	UNDER DASH RH – DR'S FAN SPEED CTR	PED WP	3	561781	561782
C 419	FR JCT BOX – RET/JAKE SELECTION	AMP MNL	3	561667	561550	C 482					
C 420						C 483	FR SERVICE CPT – ELECTRICAL SEAT	PED	2	562237	
C 421	ENGINE COMPT. - WEBASTO	AMP FF	2	562473	562474	C 484	UNDER DASH LH – FOOT DAMPER MOTOR	PED	2		562076
C 422	ENGINE COMPT. - WEBASTO	PED	2	562644	561597	C 485	UNDER DASH LH – DASH & DEFR. DAMP. M.	AMP MNL	3	561667	561558
C 423						C 486					
C 424	UNDER DASH – AUDIBLE FLASHER	AMP MNL	3	561667	561550	C 487					
C 425						C 488					
C 426	ENGINE S60 RAD. FAN CLUTCH	PED WP	3	561781	561782	C 489					
C 427						C 490					
C 428	RH SW PANEL – DASH LTS RHEOSTAT	AMP MNL	3	561667	561550	C 491					
C 429						C 492					
C 430	LH CONSOLE – PRE-HEAT TIMER	AMP FF	8	561188	562363	C 493					
C 431	LH CONSOLE – PRE-HEAT TIMER		1		560488	C 494					
C 432						C 495					
C 433						C 496					
C 434						C 497					
C 435						C 498					
C 436						C 499					

CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
C 500	FR JCT PANEL - PRODRIVER	MOLEX	6	562070	562069	C 573	UNDER DASH PANEL - T.T.LT MODULE	MOLEX	8		562465
C 501						C 574	PARCEL RACK - INDIRECT LTS BALLAST	MOLEX			562759
C 502	LH DASH PANEL - PRE- HEAT SW.	EATON	12		562763	C 575	RH PARCEL RACK - FFEDING	MOLEX	4	562507	562503
C 503						C 576	RH PARCEL RACK - FFEDING	AMP MNL	3	561667	561550
C 504						C 577	LH PARCEL RACK - FFEDING	AMP MNL	3	561667	561550
C 505						C 578	LH PARCEL RACK - FFEDING	MOLEX	4	562507	562503
C 506	FR JCT BOX - DIGITAL CLOCK	AMP CPC	4	561685	561687	C 579					
C 507	LH HAT RACK - DIGITAL CLOCK	MOLEX	4	561477	561476	C 580	LH DASH PANEL - PARCEL RACK A/C SW.	EATON	12		562763
C 508	RR JCT BOX - FAN CLUTCH RETARDER	AMP MNL	6	561552	561515	C 581	LH DASH PANEL - ELECTRICAL HORN	PED MP	2		562777
C 509	EVAP. COMPT. - NOT USED	DEUTSCH	5		562566	C 582					
C 519A	RH UNDER DASH - ENTRANCE DOOR SOL.	PNEUMAC	3		641385	C 583	LH DASH PANEL - MASTER KEY SW.	DEUTSCH	2	562486	562485
C 519B	RH UNDER DASH - ENTRANCE DOOR SOL.	PNEUMAC	3		641385	C 584	FR. SERVICE COMPT - HORN PNEU. VALVE	PNEUMAC	3		562848
C 520	RH UNDER DASH - ENTRANCE DOOR SOL.	PNEUMAC	3		641385	C 585					
C 521	RH UNDER DASH - ENTRANCE DOOR SOL.	PNEUMAC	3		641385	C 586	FR SERVICE COMPT - ACC. PNEU.VALVE	PNEUMAC	3		562848
C 522	FR JCT BOX - DAYTIME LTS MODULE	BOSCH	5		561183	C 587					
C 523	FR JCT BOX - FUSE BLOCK	PED	8	562647	562646	C 588	FR SERV. COMPT. - S.S. INTERFACE	AMP CPC	37	561645	561646
C 524	FR JCT BOX - FUSE BLOCK	PED	8	562647	562646	C 589	FR. MIRROR LH	SW CRAFT	8	562919	562920
C 525	FR JCT BOX - FUSE BLOCK	PED	8	562647	562646	C 590	FR. MIRROR RH	SW CRAFT	8	562919	562920
C 526	FR JCT BOX - FUSE BLOCK	PED	8	562647	562646	C 591	LH CONSOLE - LH MIRROR SW.	EURAMT.	8		562749
C 527	FR JCT BOX - FUSE BLOCK	PED	8	562647	562646	C 592	LH CONSOLE - RH MIRROR SW.	EURAMT.	8		562749
C 528						C 594	FRONT ROOF - DRIVER'S LTS	LEEKRAFT	2	-----	562803
C 529						C 595	RH DASH PANEL - ENTRANCE DOOR SW.	MOLEX	4	562507	562503
C 530	RR JCT BOX - FUSE BLOCK	PED	8	562647	562646	C 596	RH DASH PANEL - ENTRANCE DOOR SW.	MOLEX	4	562507	562503
C 531	RR JCT BOX - FUSE BLOCK	PED	8	562647	562646	C 597	LH DASH PANEL - DISPLAY SET SW.	AMP	5		562905
C 532	LH PARCEL RACK - A/C LIQ. SOL.	AMP MNL	2	561248	561247	C 598	LH DASH PANEL - DISPLAY SET SW.	AMP	5		562905
C 533	RH PARCEL RACK - A/C LIQ. SOL.	AMP MNL	2	561248	561247	C 599	UND. DASH - MAGN. SW CTR POS. DR'S AIR	AMP MNL	2	561248	561247
C 534						C 605	LH PARCEL RACK - A/C UNIT	AMP MNL	6	561552	561515
C 535						C 606	RH PARCEL RACK - A/C UNIT	AMP MNL	6	561552	561515
C 536						C 607	FR SERVICE COMPT - RPM SIGNAL (SPARE)	PED WP	2	561566	561690
C 537	A/C JCT BOX RESISTOR SIGN. RLY	AMP MNL	2	561248	561247	C 608	FR SERV. COMPT - SPEED SIGNAL (SPARE)	PED WP	2	561566	561690
C 538	FR SERV. CPT RH - OUTSIDE TEMP. SENS	AMP MNL	2	561248	561247	CS	FR SERVICE CPT - ECU WORLDR TR.	PED MP	32		562817
C 539	HVAC DASH MODULE OUTPUT CONN.	MOLEX	24		562780	CT	FR SERVICE CPT - ECU WORLDR TR.	PED MP	32		562824
C 540	HVAC DASH MODULE INPUT CONN.	MOLEX	22		562781	CV	FR SERVICE CPT - ECU WORLDR TR.	PED MP	32		562823
C 541						CX	CLUSTER	JAE	5		562957
C 542						CX 1	FR SERVICE CPT - ECU ABS	AMP JN	18	562792	562792
C 543						CX 2	FR SERVICE CPT - ECU ABS	AMP JN	15	562795	562795
C 544	S.S. PANEL - AUDIO SEAT	PED WP	3	561781	561782	CX 3	FR SERVICE CPT - ECU ABS	AMP JN	9	562794	562794
C 545						CX 4	FR SERVICE CPT - ECU ABS	AMP JN	6	562793	562793
C 546	FR. JCT BOX - CHARGER WIRELESS MIC.	MOLEX	2		563025	CY	CLUSTER	JAE	30		562765
C 547						LX	CLUSTER	JAE	22		562766
C 548	LH DASH PANEL - T.T.LT TEST SW.	EATON	12		562763	LY	CLUSTER	JAE	30		562767
C 549	LH DASH PANEL - ENGINE FAN OVERRIDE	EATON	12		562763	RX	CLUSTER	JAE	30		562767
C 550						WEB 1	ENGINE COMPT. - WEBASTO	AMP FF	2	562473	562474
C 551						WEB 2	ENGINE COMPT. - WEBASTO	AMP FF	2	562643	
C 552						ZF 1	FR JCT BOX - STEERING E.C.U.	HELLA	9		562929
C 553	UNDER DASH - S.S. CONTROL HEAD	MOLEX	16		562559						
C 554	UNDER DASH - S.S. CONTROL HEAD	MOLEX	16		562559						
C 555	UNDER DASH - S.S. CONTROL HEAD	MOLEX	16		562559						
C 556	UNDER DASH - RADIO FEEDING	MOLEX	2	562550	562549						
C 557	UNDER DASH - RADIO FEEDING	MOLEX	9	562556	562555						
C 558	FR. SERV. COMPT. - MIC. OUTLET	MOLEX	4	562507	562503						
C 559											
C 560											
C 561	LH PARCEL RACK - WIRELESS MIC.	MOLEX	8		562465						
C 562	LH PARCEL RACK - VCR SIGNAL	MOLEX	9	562556	562555						
C 563	FR. SERV. COMPT. - DRIVER SPEAKER	MOLEX	4	562507	562503						
C 564	FR. SERV. COMPT. - MIC. OUTLET	MOLEX	4	562507	562503						
C 565	FR. SERV. COMPT. - MIC. OUTLET	MOLEX	4	562507	562503						
C 566	FR. SERV. COMPT. - MIC. OUTLET	MOLEX	4	562507	562503						
C 567	FR. SERV. COMPT. - MIC. OUTLET	MOLEX	4	562507	562503						
C 568	S.S. PANEL - SPEAKER OUTLET	CINTCH	4	562553							
C 569	S. S. PANEL - AMPLI SIGNAL	MOLEX	9	562556	562555						
C 570	UNDER DASH PANEL - T.T.LT MODULE	MOLEX	6		562464						
C 571	UNDER DASH PANEL - T.T.LT MODULE	MOLEX	20		562778						
C 572	UNDER DASH PANEL - T.T.LT MODULE	MOLEX	18		562779						