

RESISTORS NUMBER CODE

No.	PAGE	OHM(S)	#PREV.	LOCATION	FUNCTION
RS1	5.1	11K	562307	FR JCT BOX	DDEC III-FAST IDLE
RS2	5.1	3.6K	562306	FR JCT BOX	DDEC III-FAST IDLE
RS3	9.3	1 (2)	561537	FR JCT BOX	FOG LT - RH
RS4	9.3	1 (2)	561537	FR JCT BOX	FOG LT - LH
RS5					
RS6					
RS7					
RS8					
RS9	7.1	100		UNDER DASH	DISPLAY SW. INDICATOR
RS10	25.1	82		FRONT ROOF	ELECTRICAL DEST. SIGN
RS11	15.1	2		PARCEL RACK	A/C VENTILATION UNIT
RS12	15.1	2		PARCEL RACK	A/C VENTILATION UNIT
RS13	15.1			RR JCT BOX	A/C COMPRESSOR AUX. DELAY
RS14	24.1	2K		UNDER DASH	ENTRANCE DOOR SWITCH
RS15	24.1	2K		UNDER DASH	ENTRANCE DOOR SWITCH
RS16	18.1	220	562498	FR SERV. COMPT.	KNEELING ALARM
RS17	7.2	220	562498	FR JCT BOX	FIRE ALARM
RS18	8.1	75K	064208	RR JCT BOX	FAN CLUTCH WITH A/C STD & OR RETARDER
RS19	9.3	24	562903	RR JCT BOX	CYCLOPS LTS - TAIL
RS20	17.1	1K		FR SERV COMPT.	VSS SIGNAL-VOLTAGE DIVIDER
RS21	24.1	100		RH UNDER DASH	ENTRANCE DOOR OPEN SOL.
RS22					
RS23					
RS24	9.1			UNDER DASH	HEAD LTS SWITCH LED
RS25	9.3			UNDER DASH	FOG LTS SWITCH LED
RS26					
RS27					
RS28					
RS29	27.1			GALLEY	LED SWITCH - VOLTAGE DIVIDER
RS30	27.1			GALLEY	LED SWITCH - VOLTAGE DIVIDER
RS31	27.1			GALLEY	LED SWITCH - VOLTAGE DIVIDER
RS32	27.1			GALLEY	LED SWITCH - VOLTAGE DIVIDER
RS33	27.1			GALLEY	LED SWITCH - VOLTAGE DIVIDER
RS34	27.1			GALLEY	LED SWITCH - VOLTAGE DIVIDER
RS35	27.1			GALLEY	LED SWITCH - VOLTAGE DIVIDER