

E902D	LB 1 D	GUIDE LOUDSPEAKER
E902E	LB 2 D	LOUDSPEAKERS, ROOF RIGHT
E902F	LB 3 D	LOUDSPEAKERS, ROOF LEFT
E911A	IB 4 C	PASSENGER SPEAKERS, LEFT SIDE
E911B	IB 4 C	PASSENGER SPEAKER, RIGHT SIDE
E4054A	EA 3 B	LIGHT INTO THE TOILET
E4054AL	EB 3 B	LIGHT INTO THE LEFT TOILET
E4054B	EA 3 B	LIGHT INTO THE TOILET
E4054BL	EB 3 B	LIGHT INTO THE LEFT TOILET
E4055A	HB 2 B	OCCUPIED & VACANT DISPLAY
E4055AL	HB 2 D	OCCUPIED & VACCANT DISPLAY, LEFT SIDE
E4055L	EB 3 A	OCCUPIED & VACCANT DISPLAY, LEFT SIDE
E4055LA	EA 3 A	OCCUPIED & VACANT LAMP WC
E4057A	CC 0 D	TOOL BOX COMPARTMENT LAMPS LEFT SIDE
E4057B	CC 0 D	LUGGAGE LAMPS LEFT SIDE
E4057C	CC 1 D	LUGGAGE LAMPS LEFT SIDE
E4057D	CC 1 D	LUGGAGE LAMPS LEFT SIDE
E4057E	CC 2 D	EXTRACOMPARTMENT LAMPS LEFT SIDE
E4057F	CC 2 D	LUGGAGE LAMPS RIGHT SIDE
E4057G	CC 3 D	LUGGAGE LAMPS RIGHT SIDE
E4057H	CC 3 D	LUGGAGE LAMPS LEFT SIDE
E4057J	CC 4 D	TOOL BOX COMPARTMENT LAMPS RIGHT SIDE
E4063	IB 3 C	OVER SPEED LAMP
E4064	CB 2 D	DRIVER LAMP
E4065	FA 4 D	KITCHEN LIGHT
E4066A	GA 0 D	REST COMPARTMENT LEFT LIGHT
E4066B	GA 1 D	REST COMPARTMENT RIGHT LIGHT
E4067	IB 1 C	TIME & TEMPERATURE DISPLAY
E4070	HA 3 B	EMERGENCY LAMP
E7003	FA 0 D	COFFEE MACHINE
E7004	FA 2 D	FRIDGE
EFL	IA 1 D	ELECTROSTATIC FILTER
EFR	IA 1 D	ELECTROSTATIC FILTER
F101A	AB 1 A	FUSE 50 AMP, + 30
F101B	AB 1 B	FUSE 30 AMP, B+
F104	AB 1 A	FUSE 125 AMP, A/C
F107	AB 1 B	FUSE 30 AMP, +B
FMD	HC 1 D	CENTRAL DOOR
FMT	HC 0 D	CENTRAL TOILET
G01.A	AB 0 C	BATTERY TERMINAL
G01B.B	AB 0 D	BATTERY TERMINAL
FOGL	OA 1 B	FOG PLATE LIGHTS
G01	AB 0 C	BATTERY 12 VCD
G01B	AB 0 D	BATTERY
G03	IC 4 D	ALTERNATOR
G813	LA 3 D	OUTPUT 12V

VOLVO

Volvo Bus Corporation

Document Title

WIRING DIAGRAM

Document Type

PRODUCT SCHEMATIC

Document No

21250316

Issue Index

01

Volume No

02

Page No

4(11)