

G813	OUTPUT 12V	LA 3 D
G814A	OUTPUT 24V	LA 3 D
H01	ELECTRIC HORN A	IA 3 B
H02	ELECTRIC HORN B	IA 4 B
H06R	BUZZER REVERSE	OA 3 C
H07	HORN, KNEELING ALARM	DA 4 D
H12	INDICATOR LAMP, EMERGENCY WINDOWS	JC 4 C
H13A	SPEAKER SERVICE KIT	LF 0 B
H13B	SPEAKER, SERVICE KIT	LF 0 B
H13C	SPEAKER, SERVICE KIT	LF 0 C
H13D	SPEAKER SERVICE KIT	LF 0 D
H13E	SPEAKER, SERVICE KIT	LF 1 B
H13F	SPEAKER, SERVICE KIT	LF 1 B
H13G	SPEAKER, SERVICE KIT	LF 1 C
H13H	SPEAKER, SERVICE KIT	LF 1 D
H13I	SPEAKER, SERVICE KIT	LF 1 B
H13J	SPEAKER, SERVICE KIT	LF 1 B
H13K	SPEAKER, SERVICE KIT	LF 1 C
H13L	SPEAKER SERVICE KIT	LF 1 D
H13M	SPEAKER, SERVICE KIT	LF 1 D
H13N	SPEAKER, SERVICE KIT	LF 1 E
H853	BUZZER	EA 2 C
H853L	BUZZER, LEFT TOILET	EB 2 C
H860	OVER SPEED BUZZER	IB 3 C
H5013	OVER SPEED TELLTALE	IB 3 C
J1	SPLICE	PA 1 B
J2	SPLICE	PA 1 B
J3	SPLICE	CA 1 A
J4	SPLICE	EA 4 C
J5	SPLICE	CB 3 A
J6	SPLICE	PA 1 B
J7	SPLICE	CB 1 E
J8	SPLICE	PA 3 D
J9	SPLICE	PA 3 D
J10	SPLICE	PA 4 D
J11	SPLICE	BA 1 B
J12	SPLICE	BA 1 B
J13	SPLICE	PA 4 D
J14	SPLICE	AA 0 D
J16	SPLICE	PA 4 D
J17	SPLICE	AA 0 E
J18	SPLICE	PA 4 D
J19	SPLICE	PA 0 D
J20	SPLICE	GA 0 A
J21	SPLICE	CE 1 D
J22	SPLICE	PA 0 D
J23	SPLICE	EA 3 B
J24	SPLICE	PA 2 D
J25	SPLICE	PA 1 D
J26	SPLICE	PA 1 D
J27	SPLICE	CE 1 C

**VOLVO**

Volvo Bus Corporation

Document Title

**WIRING DIAGRAM**

Document Type

**PRODUCT SCHEMATIC**

Document No

**21894999**

Issue Index

**02**

Volume No

**02**

Page No

**6(14)**