

CIRCUIT BREAKERS CODE

No.	PAGE	AMP.	#PREV.	LOCATION	FUNCTION	No.	PAGE	AMP.	#PREV	LOCATION	FUNCTION
CB 1	2.1	40A	562686	BAT. CPT.	12V IGNITION	CB 59					
CB 2	1.1	40A	870093	BAT. CPT.	12V HOT WIRE	CB 60					
CB 3	1.1	40A	562686	BAT. CPT.	12V FEED RR. JCT. BOX	CB 61					
CB 4	1.1	70A	562687	BAT. CPT.	12V FEED FR. JCT. BOX	CB 62					
CB 5	1.1	30A	870690	BAT. CPT.	24V HOT WIRE	CB 63					
CB 6	1.1	90A	562683	BAT. CPT.	24V FEED RR. JCT. BOX	CB 64					
CB 7	1.1	90A	562683	BAT. CPT.	24V FEED FR. JCT. BOX	CB 65					
CB 8	1.1	150A	560299	BAT. CPT.	24V EVAPORATOR FAN MOTOR	CB 66					
CB 9						CB 67					
CB 10	4.1	8A	561791	FR. JCT. BOX	MASTER KEY SWITCH	CB 68					
CB 11						CB 69					
CB 12						CB 70					
CB 13						CB 71	15.1	10A	561792	RR. JCT. BOX	A/C & HEAT LOGIC PANEL
CB 14						CB 72	15.1	10A	561792	RR. JCT. BOX	A/C COMPRESSOR CLUTCH
CB 15						CB 73	15.1	15A	561793	RR. JCT. BOX	WATER PUMP
CB 16	4.1	8A	561791	RR. JCT. BOX	ENGINE-RR. CTRL & START SW.	CB 74					
CB 17						CB 75					
CB 18	4.1	6A	561790	RR. JCT. BOX	ENGINE-FR. CTRL SW.	CB 76					
CB 19	5.1	15A	561793	BAT. CPT.	E.C.M. DDEC III 12V POWER	CB 77	15.2	40A	870093	BAT. CPT.	CONDENSER FAN MOTOR RH
CB 20	5.1	15A	561793	BAT. CPT.	E.C.M. DDEC III 12V POWER	CB 78	15.2	40A	870093	BAT. CPT.	CONDENSER FAN MOTOR LH
CB 21	5.1	10A	561792	RR. JCT. BOX	E.C.M. DDEC AND WTEC 12V IGNITION	CB 79	15.2	15A	561793	FR. JCT. BOX	DRIVER'S HTR FAN SPEED CTRL MODULE
CB 22						CB 80					
CB 23						CB 81					
CB 24	6.1	20A	561794	BAT. CPT.	WORLD TRANSMISSION 12V POWER	CB 82					
CB 25						CB 83					
CB 26	9.3	8A	561791	RR. JCT. BOX	BACK-UP LTS	CB 84					
CB 27	7.1	8A	561791	FR. JCT. BOX	24V IGNITION DASH ACCESSORIES	CB 85	11.2	10A	561790	FR. JCT. BOX	ENTRANCE DOOR & STEP LTS
CB 28	7.2	6A	561790	FR. JCT. BOX	12V IGNITION DASH ACCESSORIES	CB 86					
CB 29						CB 87					
CB 30						CB 88					
CB 31						CB 89					
CB 32						CB 90					
CB 33						CB 91					
CB 34	9.3	6A	561790	RR. JCT. BOX	BACK-UP ALARM	CB 92					
CB 35	9.3	15A	561790	FR. JCT. BOX	FOG & HAZARD DASH SW.	CB 93					
CB 36						CB 94					
CB 37	9.1	6A	561790	FR. JCT. BOX	HEAD & MULTI-FUNCTION LEVEL SW.	CB 95					
CB 38	9.1	3A	561797	FR. JCT. BOX	FR. MARKER LTS	CB 96					
CB 39	9.1	6A	561790	FR. JCT. BOX	CLEARANCE & IDENTIFICATION LTS	CB 97					
CB 40	9.1	3A	561797	FR. JCT. BOX	FR. CLEARANCE & IDENTIFICATION LTS	CB 98					
CB 41	9.1	3A	561797	RR. JCT. BOX	RR. CLEARANCE & IDENTIFICATION LTS	CB 99					
CB 42	9.1	8A	561791	RR. JCT. BOX	RR. TAIL & LICENCE LTS	CB 102					
CB 43	9.1	20A	561794	FR. JCT. BOX	HEADLAMP (HI)	CB 103					
CB 44	9.1	15A	561793	FR. JCT. BOX	HEADLAMP (LO)	CB 104					
CB 45	9.2	10A	561792	FR. JCT. BOX	WIPER CTRL MULTI-FUNCTION LEVEL SW.	CB 105	22.1	6A	561790	FR. JCT. BOX	E.C.U. ABS
CB 46	9.2	10A	561792	FR. JCT. BOX	FLASHER & HAZARD UNIT	CB 106	22.1	15A	561793	FR. JCT. BOX	E.C.U. ABS
CB 47						CB 115	12.1	8A	561791	FR. JCT. BOX	KEYLESS MODULE
CB 48	9.3	6A	561790	FR. JCT. BOX	STOP LTS PRESSURE SW.	CB 118	12.1	20A	561794	RR. JCT. BOX	KEYLESS ENTRY SYS. - LUGGAGE DOOR LOCK
CB 49	9.3	6A	561790	RR. JCT. BOX	STOP & CYCLOP LTS	CB 120	12.1	20A	561794	RR. JCT. BOX	KEYLESS ENTRY SYS. - LUGGAGE DOOR LOCK
CB 50						CB 123	13.1	25A	561795	FR. JCT. BOX	DRIVER'S SEAT ELECTRICAL ADJUSTMENT
CB 51	10.1	10A	561792	FR. JCT. BOX	UPPER WIPER CTRL SW.	CB 124	8.1	6A	561790	RR. JCT. BOX	RADIATOR FAN CLUTCH
CB 52	11.1	15A	561793	RR. JCT. BOX	LUGGAGE & DOOR AJAR LTS	CB 129	7.2	6A	561790	FR. JCT. BOX	CLUSTER
CB 53						CB 130	23.1	6A	561790	FR. JCT. BOX	TELL TALE LIGHTS MODULE
CB 54						CB 131	4.2	6A	561790	RR. JCT BOX	24 V. IGN. - ALTERNATOR BOSCH
CB 55						CB 132	4.2	6A	561790	RR. JCT BOX	12 V. IGN. - ALTERNATOR BOSCH
CB 56											
CB 57	11.2	8A	561791	FR. JCT. BOX	DASH LTS RHEOSTAT						
CB 58	15.1	6A	561790	FR. JCT. BOX	HVAC DASH MODULE						