

FUSES CODE

No.	PAGE	AMP.	#PREV.	LOCATION	FUNCTION	No	PAGE	AMP.	#PREV	LOCATION	FUNCTION
F 1	6.1	10A	562407	RR. JCT. BOX	WORLD TRANSMISSION 12V BATTERY						
F 2	6.1	10A	562407	RR. JCT. BOX	WORLD TRANSMISSION 12V IGNITION						
F 3	7.2	20A	562605	FR. JCT. BOX	ELECTRICAL HORNS						
F 4	7.2	5A	562259	FR. JCT. BOX	FIRE ALARM						
F 5											
F 6	5.1	5A	562602	FR. JCT. BOX	CRUISE DECEL SW.						
F 7	8.1	5A	562602	FR. JCT. BOX	PARKING BRAKE PRESSURE SW.						
F 8	9.2	10A	562407	FR. JCT. BOX	CORNERING LTS						
F 9	9.3	15A	562604	RR. JCT. BOX	DOCKING LTS						
F 10	9.3	15A	562604	FR. JCT. BOX	FOG LTS						
F 11	11.1	5A	562259	FR. JCT. BOX	FRONT SERVICE CPT LTS						
F 12	17.1	3A	560893	FR. JCT. BOX	STEERING CONTROL						
F 13											
F 14	11.2	15A	562602	FR. JCT. BOX	DRIVER'S LTS						
F 15											
F 16											
F 17											
F 18											
F 19											
F 20											
F 21	14.2	10A	560061	RR. JCT. BOX	FUEL PRIME PUMP						
F 22	19.1	10A	562407	FR. JCT. BOX	POWER 12V OUTLET						
F 23	19.1	15A	562604	FR. JCT. BOX	DRIVER'S WINDOW LIFTER						
F 24	19.1	15A	562407	FR. JCT. BOX	CIGAR LIGHTER						
F 25	19.1	3 A	562599	FR. JCT. BOX	SUN VISOR						
F 26	14.1	7.5A	562259	FR. JCT. BOX	WATER HTR TIMER						
F 27											
F 28											
F 29	15.3	15A	562604	FR. JCT BOX	AUX. A/C UNIT						
F 30											
F 31											
F 32											
F 33											
F 34											
F 35											
F 36											
F 37											
F 38											
F 39											
F 40											
F 41											
F 42											
F 43	1.2	3A	562599	BATT.CPT	12V SIGNAL TO BATT. MONITOR						
F 44	1.2	3A	562599	BATT.CPT	24V SIGNAL TO BATT. MONITOR						
F 45											
F 46	16.1	7.5A	562602	FR. JCT. BOX	MIRROR ADJUST & HEATED 24V SPARTAN						
F 47	16.2 16.3	7.5A	562602	FR. JCT. BOX	MIRROR ADJUST & HEATED 12V RAMCO						
F 48											
F 49											
F 50											
F 51											
F 52											
F 53	20.1	3A	560893	RR. JCT. BOX	BACK-UP MONITOR DOOR SOLENOID						
F 54											
F 55	20.1	7.5A	562602	RR. JCT. BOX	BACK-UP MONITOR CAMERA HEATER						
F 56	20.1	7.5A	562602	RR. JCT. BOX	BACK-UP MONITOR CAMERA						
F 57	4.1	1A	560893	RR. JCT. BOX	GENERATOR RUN RELAY						