

WIRING DIAGRAM INDEX

Information Pages				
Multiplexed Devices Index	B1 – B8			
Arrangement – Harness	C1			
Glossary	D			
Circuit Number Listing	E			
Circuit Breaker code	F			
Connectors code	G			
Diode Number Code	H			
Resistors Number Code	J			
Fuses Code	L			
Relay Code	K			
Functions				
A				
Adaptive Cruise Control	38.1			
Automatic Fire Supp. System	40.1			
B				
Back-up Camera	28.1			
Back-up lights and alarm	26.3			
Battery and Equalizer	1.1			
Battery Charger	17.1			
Brake	12.1			
C				
Charging System	3.2			
Clearance lights rear & front	26.1,26.2			
Cluster	10.1			
Converter interface	36.1			
Cornering Lights	26.3			
Cruise control	14.1			
D				
Dash Lights	19.1			
Differential lock	37.1			
Docking Lights	26.3			
Driver's Light and Backlight	19.1			
Driver's Power Window	30.1			
Driver's seat	35.2			
E				
Engine block Heater	11.1			
Engine brake and Retarder	12.1			
Engine compt lighting	25.1			
Engine Start	3.2			
Engine ECM	14.1			
Engine Override	14.1			
Entrance door	29.1			
Ether Switch	13.1			
Engine bloc heater	11.1			
ESP	16.1			
F				
Fast Idle	14.1			
Fire Alarm	9.1			
Flashers	26.1,26.2			
Fog lights	26.3			
Fuel Sender	10.1			
Fuel Prime Pump	13.1			
Fuel water Filter	13.1			
Fuel Filter Preheater	13.1			
G				
Grounds	2.1			
H				
Hazard	26.1			
Head Lights	26.1			
Horn	9.1			
Hvac Defroster	18.1			
Hvac Passenger	18.2			
Hvac Driver onlyr	18.3			
K				
Keyless keypad	29.1			
L				
Level low	32.1			
Luggage compt lighting	25.1			
Luggage door Lock/Unlock	33.1			
Luggage door switches	24.1			
M				
Main Distribution Ignition & Batt.	3.1			
Main Distribution Wake-Up	3.3			
Marker Lights	26.1,26.2			
Mirror Ramco	31.1			
Multiplexing power distribution	7.1			
Multiplexing Network	6.1			
P				
Park Brake Sensor	12.1			
Trailer Brake Sensor	12.1			
Parking Brake Release Switch	32.1			
Power Distribution FJB	4.1			
Power Distribution RJB	5.1			
Power Outlet	30.1			
Prime Pump	13.1			
Pneumatic Cut-Out Acc sol	9.1			
R				
Radiator Fan Clutch	13.1			
Rear junction box door fan	11.1			
S				
Service Brake Relay	12.1			
Slide out (1-2)	20.1			
Slide out (3-4)	20.2			
Spare Wires	8.1			
Stop lights	26.2			
Sun Visor	38.1			
Steering Control ZF	37.1			
Steering Multi-functions	38.1			
T				
Tag	32.1			
Tail and Licence Lights	26.2			
Test Switch	9.1			
Transmission ECU	15.1-15.2			
Trailer Package	26.4			
Tire Pressure Monitor. Sys.	39.1			
W				
Window Ajar &Awning	27.1			
Wiper & Washer	34.1			