



**NOTE :**

CONTROL VALVE OPT. "LOW-BUOY", "A" OR "B" SETTING:

POSITION "A": VALVE OPEN .  
AIR FLOW BETWEEN SUPPLY (S) AND DELIVERY (D), LOW-BUOY IS NOT IN FUNCTION.

POSITION "B": VALVE CLOSED .  
AIR DOES NOT FLOW BETWEEN SUPPLY (S) AND DELIVERY (D), LOW-BUOY IS IN FUNCTION.

BASIC ON D140261 P.1 , COMPLETE DIAGRAM

ITEM	DESCRIPTION
500	3/8" O.D. BLUE TUBE
501	1/2" O.D. BLUE TUBE
502	1/4" O.D. BLUE TUBE

D140261 P.5 REV.A  
 COACH XL2 45'  
 FRONT BEAM AXLE SUSPENSION  
 WITH OPTION FRONT KNEELING  
 LOW-BUOY AND HIGH-BUOY COMBINATION