

|        |                                      |        |
|--------|--------------------------------------|--------|
| B22    | SENSOR, OUTDOOR TEMPERATURE          | ND 1 C |
| B958M  | SENSOR, PRINCIPAL TANK MIDDLE TOILET | EC 2 D |
| B959M  | SENSOR, SOIL TANK MIDDLE TOILET      | EC 3 D |
| B961A  | SENSOR EMERGENCY WINDOWS             | JC 1 B |
| B961B  | SENSOR EMERGENCY WINDOWS             | JC 2 B |
| B961C  | SENSOR EMERGENCY WINDOWS             | JC 3 B |
| B961D  | SENSOR EMERGENCY WINDOWS             | JC 3 B |
| B961E  | SENSOR EMERGENCY WINDOWS             | JC 0 B |
| B961F  | SENSOR EMERGENCY WINDOWS             | JC 0 B |
| B961G  | SENSOR EMERGENCY WINDOWS             | JC 1 B |
| B961H  | SENSOR EMERGENCY WINDOWS             | JC 2 B |
| B962   | SENSOR, OPTICAL FIRE DETECTOR        | ID 0 D |
| B963   | SENSOR, OUTDOOR TEMPERATURE          | GC 2 C |
| B7070  | INDUCTIVE SENSOR, ENGINE HATCH OPEN  | OB 3 B |
| B7072  | DEFROSTER TEMP. SENSOR               | NA 1 E |
| B7073  | OUTSIDE TEMP. SENSOR                 | NA 4 B |
| B7074  | DRIVER TEMP. SENSOR                  | NA 1 E |
| B7075A | PASSENGER SENSOR, CLIMATE DOT        | NC 2 D |
| B7075B | PASSENGER SENSOR                     | NC 2 B |
| BB3:6  | BBI, DRL SIGNAL                      | OC 1 C |
| BB7/2  | REVERSE LIGHT                        | AA 3 D |
| BB7/3  | DIRECTION REAR LEFT                  | AA 3 D |
| BB7/4  | DIRECTION REAR RIGHT                 | AA 3 D |
| BB7/7  | PARKING LIGHT LEFT                   | AA 3 D |
| BB7/8  | PARKING LIGHT RIGHT                  | AA 3 D |
| BB7/9  | LUGGAGE HATCH                        | AA 4 D |
| BB7/10 | ENGINE HATCH                         | AA 4 D |
| D972A  | DRIVER INTERPHONE                    | GA 2 B |
| D972B  | CABIN INTERPHONE                     | GA 2 C |
| DAH    | DIODE, AUXILIARY HEATER              | ND 2 B |
| DB9    | CONNECTOR DB9 SERIAL                 | IF 0 D |
| DHA    | DIODE, HOST CALL                     | CC 4 C |
| DHB    | DIODE, HOST CALL                     | CC 4 C |
| DRB    | DIODE, READING LIGHTS                | CC 0 D |
| DRC    | DIODE, READING LIGHTS                | CC 1 D |
| E03    | LAMP, SPOT LIGHT                     | GB 0 D |
| E03A   | LAMP, WCL                            | GB 0 D |
| E07LR  | FOG LIGHT LEFT REAR                  | OA 1 C |
| E07RR  | FOG LIGHT RIGHT REAR                 | OA 2 C |
| E09RB  | BREAK LIGHT MIDDLE                   | OA 4 C |
| E09RC  | LAMP, CENTER STOP LAMP CA            | OA 4 C |
| E10L   | TAIL AND BREAK LIGHT LEFT            | OA 0 C |
| E10LB  | LICENSE PLATE LEFT                   | OA 1 C |
| E10R   | TAIL AND BREAK LIGHT RIGHT           | OA 3 C |
| E10RB  | LICENSE PLATE RIGHT                  | OA 2 C |
| E11LF  | SIDE-MARKER LAMP MIDDLE LEFT         | OB 0 C |
| E11RR  | SIDE-MARKER FRONT RIGHT              | OB 1 C |
| E11TL  | SIDE-MARKER LAMP REAR LEFT           | OB 0 C |
| E11TR  | SIDE-MARKER LAMP REAR RIGHT          | OB 1 C |
| E13    | DIRECTION INDICATOR                  | OB 2 C |
| E14    | LAMP, BEACON WARNING LAMP            | GB 4 D |

**VOLVO**

Volvo Bus Corporation

Document Title

**WIRING DIAGRAM**

Document Type

**PRODUCT SCHEMATIC**

Document No

**21894999**

Issue Index

**02**

Volume No

**02**

Page No

**3(14)**