

| NO. | PAGE | AMP | •PREVOST | LOCATION | FUNCTION |
|-----|-------|-----|----------|-----------------|------------------------------------|
| D1 | 5 | 3A | 561740 | FR JCT BOX | PRIMARY LO-AIR SONALERT |
| D2 | 5 | 3A | 561740 | FR JCT BOX | SECONDARY LO-AIR SONALERT |
| D3 | 12-13 | 3A | 063849 | FR JCT BOX | A/C (FULL AIR) - CONTROL SW. |
| D4 | 12-13 | 3A | 063849 | FR JCT BOX | WATER HEATER ON SIGNAL |
| D5 | 11 | 3A | 063849 | FR JCT BOX | KEYLESS - CENTER DOOR AJAR ALARM |
| D6 | 1 | 3A | 060798 | RR JCT BOX | STARTER - SUPPRESSOR COIL RLY |
| D17 | 7 | 3A | 561740 | FR JCT BOX | HAZARD LH |
| D18 | 7 | 3A | 561740 | FR JCT BOX | HAZARD RH |
| D19 | 6 | 3A | 561740 | FR JCT BOX | DAYTIME RUNNING LTS |
| D20 | 6 | 3A | 561740 | FR JCT BOX | DAYTIME RUNNING LTS |
| D21 | 7 | 3A | 561740 | UNDER DASH | AUDIBLE FLASHER RLY LH |
| D22 | 7 | 3A | 561740 | UNDER DASH | AUDIBLE FLASHER RLY RH |
| D23 | 18 | 3A | 063763 | RR JCT BOX | PRE WATER HEATER (ESPAR PRIOR) |
| D24 | 5 | 3A | 561740 | FR JCT BOX | UNLOAD TAG SYSTEM |
| D26 | 20 | 3A | 560931 | FR SERVICE CPT. | LEVEL LOW SYSTEM |
| D27 | 20 | 3A | 560931 | FR SERVICE CPT. | LEVEL LOW SYSTEM |
| D60 | 12 | 3A | 561740 | RR JCT BOX | A/C STD - COMPR. CLUTCH |
| D61 | 13 | 3A | 561740 | RR JCT BOX | A/C FULL AIR - COMPR. CLUTCH |
| D83 | 9 | 3A | 561740 | RR JCT BOX | RAD. FAN CLUTCH W. A/C OR RETARDER |