

## WIRING DIAGRAM INDEX

<b>A</b> A/C, HEAT & VENT. SYSTEM      Page: 13.1 AIR DRYER      Page: 8.1 ALARM & SIGNAL      Page: 7.2 ABS      Page: 21.1 ARRANGEMENT - CABLE      Page: B ARRANGEMENT - HARNESS      Page: C ARRANGEMENT - SPARE WIRE      Page: D	DISTRIBUTION 12V, 24V      Page: 1.1 DISTRIB. 12V DISC., IGN & HOT WIRE      Page: 2.1 DRIVER'S WINDOW LIFTER      Page: 14.1  <b>E</b> ENGINE BLOCK HEATER      Page: 12.1 ENGINE BRAKE SYSTEM      Page: 19.1 ENGINE CONTROL      Page: 4.1 ENTRANCE DOOR SEDAN      Page: 16.1 ETHER COLD START      Page: 8.1 EXTERIOR LIGHTING      Page: 9.1  <b>F</b> FAN-CLUTCH RADIATOR      Page: 8.1 FAST IDLE - DDEC      Page: 5.1 FIRE DETECTOR      Page: 7.2 FRONT DESTINATION SIGN      Page: 17.1 FRONT CAMERA      Page: 20.7 FUEL WATER FILTER      Page: 8.1 FUEL PRIME PUMP      Page: 12.1  <b>G</b> GALLEY ACCESSORIES      Page: 23.1 GROUND SYSTEM      Page: 3.1  <b>H</b> HIGH BUOY      Page: 18.1 HOTESS CHIME      Page: 12.1  <b>I</b> INTERIOR LIGHTING      Page: 11.1 INTERCOM      Page: 27.1  <b>K</b> KNEELING SYSTEM      Page: 18.1  <b>L</b> LAVATORY      Page: 17.1 LOW BUOY      Page: 18.1	LUGGAGE DOOR LOCK      Page: 19.1  <b>M</b> MIRROR-REAR VIEW      Page: 24.1  <b>P</b> PARKING BRAKE SWITCH      Page: 8.1 POWER 12V OUTLET      Page: 14.1 PRODRIVER      Page: 8.1  <b>R</b> RETARDER - WORLD TRANSM.      Page: 19.1  <b>S</b> SPEED SWITCH (MANUAL TRANS.)      15.1 SOUND & VIDEO SYSTEM      Page: 20.1 SPEAKER PASSENGER      Page: 20.2 SUN VISOR      Page: 14.1  <b>T</b> TELL TALE LIGHT MODULES      Page 28.1 TRANSMISSION - MANUAL      Page: 15.1 TRANSMISSION - WORLD      Page: 6.1 TRANSMISSION - EATON      Page: 6.3  <b>W</b> WATER HEATER PRE-HEAT      Page: 26.1 WATER TANK HEATER LAVATORY      Page: 12.1 WHEEL CHAIR LIFT - RICON 9000      Page: 25.2 WHEEL CHAIR LIFT - STEW. & STEV.      Page: 25.1 WINDOW AJAR      Page: 7.2 WINDSHIELD (UP) FAN DEFROSTOR      Page: 22.1 WINDSHIELD (UP) HEATED      Page: 22.1 WIPER & WASHER      Page: 10.1
<b>B</b> BACK-UP ALARM      Page: 9.3 BACK-UP MONITOR      Page: 27.1 BATTERY CHARGER      Page: 11.4 BATTERY STANDARD AND 8D      Page: 1.2		
<b>C</b> CLUSTER      Page: 7.1 CHARGING SYSTEM      Page: 4.2 CIGAR LIGHTER      Page: 14.1 CODE - CIRCUIT NUMBER      Page: E CODE - CIRCUIT BREAKER      Page: F CODE - CONNECTOR      Page: G CODE - DIODE      Page: H CODE - RELAY      Page: I CODE - RESISTOR      Page: J CODE - WIRING KEY      Page: K CODE - FUSE      Page: L CODE - MODULE      Page: M CRUISE CONTROL - DDEC      Page: 5.1 CB OPTION      Page: 20.5		
<b>D</b> DDEC III & IV      Page: 5.1 DIGITAL CLOCK      Page: 14.1		