

DIODES NUMBER CODE

No.	PAGE	AMP	#PREV.	LOCATION	FUNCTION	No.	PAGE	AMP	#PREV.	LOCATION	FUNCTION
D1						D60	15.2	3A	561740	RJB A/C JCT PANEL	A/C COMPR.CLUTCH SUPPRESSOR
D2						D61					
D3	1.1	3A	561740	BATT. CPT	24 V. DISC, SWICH RELAY	D62	15.2	3A	561740	RJB A/C JCT PANEL	WATER PUMP FEED
D4	9.2	3A	561740	FR JCT BOX	WARNING HAZARD-RH	D63					
D5	9.2	3A	561740	FR JCT BOX	WARNING HAZARD-LH	D64					
D6						D65	15.2	3A	561740	RJB A/C JCT PANEL	WATER PUMP - PRE-HEAT FEED
D7						D66	15.2	3A	561740	RJB A/C JCT PANEL	WATER VALVE - HEAT SW. FEED
D8						D67	9.2	3A	561740	UNDER DASH	AUDIBLE FLASHER RLY - RH
D9						D68	9.2	3A	561740	UNDER DASH	AUDIBLE FLASHER RLY - LH
D10						D69					
D11						D70					
D12						D71					
D13						D72					
D14						D73					
D15						D74					
D16						D75	4.1	3A	560931	BAT CPT	STARTER-SUPPRESSOR COIL RLY
D17	9.2	3A	561740	FR JCT BOX	WARNING HAZARD-LH	D76					
D18	9.2	3A	561740	FR JCT BOX	WARNING HAZARD-RH	D77					
D19	9.1	3A	561740	FR JCT BOX	DAYTIME RUN LTS-PARK BRK CALL SW.	D78	14.1	3A	561740	LH CONSOLE	PRE-HEAT WATER HEATER SW.
D20	9.1	3A	561740	FR JCT BOX	DAYTIME RUN LTS-HEAD LT SW	D79	14.1	3A	561740	LH CONSOLE	PRE-HEAT WATER HEATER SW.
D21						D80					
D22	18.1	3A	561740	FR SERVICE CPT	LEVEL LOW	D81					
D23	18.1	3A	561740	FR SERVICE CPT	LEVEL LOW	D82					
D25	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.	D83	8.1	3A	561740	RR JCT BOX	FAN CLUTCH W/RETARDER
D26	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.	D84	15.2	3A	561740	RJB A/C JCT PANEL	WATER VALVE
D27	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.	D85	15.2	3A	561740	RJB A/C JCT PANEL	WATER PUMP
D28	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.	DA1	4.2	3A	561740	RR JCT BOX	ALTERNATOR BOSCH
D29	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.	D A2	4.2	3A	561740	RR JCT BOX	ALTERNATOR BOSCH
D30	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.	DF1	8.1	3A	561740	RR JCT BOX	FAN CLUTCH - SUPRESSOR
D31						DF2	8.1	3A	561740	RR JCT BOX	FAN CLUTCH - SUPRESSOR
D32											
D33											
D34											
D35											
D36											
D37											
D38											
D39	9.2	3A	561740	FR JCT BOX	CORNERING LT -LH						
D40	9.2	3A	561740	FR JCT BOX	FR DOCKING LT LH -HI						
D41	9.2	3A	561740	FR JCT BOX	FR DOCKING LT RH -HI						
D42	9.2	3A	561740	FR JCT BOX	CORNERING LT -RH						
D43	10.1	3A	561740	WIPER MOTOR	LOWER WIPER MOTOR SUPPRESSOR						
D44	10.1	3A	561740	WIPER MOTOR	LOWER WIPER MOTOR SUPPRESSOR						
D45	10.1	3A	561740	WIPER MOTOR	UPPER WIPER MOTOR SUPPRESSOR						
D46											
D47											
D48											
D49											
D50											
D51	11.2	3A	561740	FR JCT BOX	ENTRANCE DOOR -STEP LTS						
D52											
D53	9.3	3A	561740	FR JCT BOX	CORNERING LT -GROUND						
D54	20.1	3A	561740	RR JCT BOX	BACK-UP MONITOR						
D55											
D56	9.2	12A	560863	FR JCT BOX	FR DOCKING LT LH -LOW						
D57	9.2	12A	560863	FR JCT BOX	FR DOCKING LT RH -LOW						
D58											
D59	15.2	3A	561740	RJB A/C JCT PANEL	A/C & HEAT WATER VALVE						