

RELAYS NUMBER CODE

NO.	PAGE	COLL	V	#PREV.	LOCATION	FUNCTION
R1	8	24V	24V	561707	RR JCT BOX	FAN CLUTCH WIRET SPEED 1
R2	8	24V	24V	561707	RR JCT BOX	FAN CLUTCH WIRET. SPEED 2
R3	8	24V	24V	560772	RR JCT BOX	TIME DELAY
R4	16	24V	24V	561707	UNDER DASH RH	ENTRANCE DOOR SEDAN (LATCH)
R5	16	24V	24V	561707	UNDER DASH RH	ENTRANCE DOOR SEDAN (PRESS. SW.)
R6	16	24V	24V	561707	UNDER DASH RH	ENTRANCE DOOR SEDAN (LIGHT)
R7	16	24V	24V	561707	UNDER DASH RH	ENTRANCE DOOR SEDAN (VALVE)
R8	1,1	24V	24V	561991	RR JCT BOX	ENGINE RUN (24) FR
R9	2	24V	24V	561991	BATT. CPT.	ENGINE RUN (12) FR & RR
R10	2	24V	24V	561707	BATT. CPT.	FIELD RELAY
R11	4	24V	24V	561005	BATT. CPT.	STARTING MOTOR
R12	5	24V	24V	561707	RR JCT BOX	CRUISE CTR. STOP SIGN.
R13	5	24V	24V	561707	RR JCT BOX	STOP LTS. PARKING BRAKE
R14	5	24V	24V	561707	RR JCT BOX	FAST IDLE
R15	6	24V	24V	561707	RR JCT BOX	12V IGNITION WT
R16	6	24V	24V	561707	RR JCT BOX	BACK-UP LTS
R17	9,3	24V	24V	561707	RR JCT BOX	12V IGNITION DDEC3
R18	9,3	24V	24V	562092	RR JCT BOX	ELECTRICAL HORNS
R19	7	24V	24V	561707	RR JCT BOX	FOG LTS
R20	9,1	24V	24V	561707	RR JCT BOX	BLINKER
R21	9,1	24V	24V	561707	RR JCT BOX	FR MARKER LTS
R22	9,2	24V	24V	561707	RR JCT BOX	IDENT. & CLEARANCE LTS
R23	9,2	24V	24V	561707	RR JCT BOX	TAIL LICENSE MARKER LTS
R24	9,2	24V	24V	561707	RR JCT BOX	D R L PARK BRK CUT-IN
R25	9,3	24V	24V	561707	RR JCT BOX	HEAD LAMP (H)
R26	9,3	24V	24V	561707	RR JCT BOX	HEAD LAMP (L)
R27	11,2	24V	24V	561707	RR JCT BOX	L.H. DIRECTIONAL LT
R28	11,2	24V	24V	561707	RR JCT BOX	R.H. DIRECTIONAL LT
R29	11,3	24V	24V	561707	RR JCT BOX	R.H. CORNERING LT
R30	11,3	24V	24V	561707	RR JCT BOX	L.H. CORNERING LT
R31	11,3	24V	24V	561707	RR JCT BOX	STOP LTS
R32	11,4	24V	24V	561707	RR JCT BOX	AISLE & EMERG. EXIT - LTS
R33	13,1	24V	24V	562092	RR JCT BOX	DASH LTS RHEOSTAT
R34	13,1	24V	24V	561707	RR JCT BOX	READING LTS R.H.
R35	13,1	24V	24V	561707	RR JCT BOX	READING LTS L.H.
R36	13,1	24V	24V	561707	RR JCT BOX	GENERAL LTS
R37	10	24V	24V	561707	RR JCT BOX	24V FLUORESCENT
R38	10	24V	24V	561707	RR JCT BOX	BLOWER CUT-IN RLY
R39	13,2	24V	24V	561005	RR JCT BOX	A/C LOGIC PANEL
R40	13,2	24V	24V	561014	RR JCT BOX	WATER PUMP
R41	13,2	24V	24V	561005	BATT. CPT.	A/C COMPRESSOR CLUTCH
R42	18	24V	24V	561005	BATT. CPT.	KNEELING LT
R43	18	24V	24V	561707	RR JCT BOX	CONDENSER FAN MOTOR
R44	18	24V	24V	561707	RR JCT BOX	CONDENSER SPEED CTR HI
R45	18	24V	24V	561707	RR JCT BOX	CONDENSER SPEED CTR HI
R46	23	24V	24V	561707	RR JCT BOX	KNEELING SYSTEM
R47	23	24V	24V	561707	RR JCT BOX	KNEELING SYSTEM
R48	23	24V	24V	561707	RR JCT BOX	GALLEY LIQUID CONTAINERS
R49	21	24V	24V	561707	RR JCT BOX	GALLEY COMP
R50	21	24V	24V	561707	RR JCT BOX	COFFEE MAKER
R51	21	24V	24V	561707	RR JCT BOX	ABS - SERVICE BRK RLY
R52	21	24V	24V	561707	RR JCT BOX	ABS - VTR RLY
R53	1,1	24V	24V	561707	RR JCT BOX	ABS - WARNING RLY
R54	1,1	24V	24V	561991	RR JCT BOX	ABS - VTR RLY
R55	1,1	24V	24V	561991	BATT. CPT.	ENGINE RUN (24) RR
R56	9,3	24V	24V	562092	RR JCT BOX	12V CUT OUT RLY RR
R57	9,3	24V	24V	561707	RR JCT BOX	12V CUT OUT RLY FR
R58	20,1	24V	24V	561707	RR JCT BOX	DOCKING LTS
R59	20,1	24V	24V	561707	RR JCT BOX	STOP LTS. JACOB & RET. SIGNAL
R60	20,1	24V	24V	561991	RR JCT PANEL	SOUND SYSTEM VIDEO
R61	20,1	24V	24V	561991	RR JCT PANEL	SOUND SYSTEM RADIO
R62	20,1	24V	24V	562092	RR JCT PANEL	SOUND SYSTEM AMPLIFIER
R63	23	24V	24V	561707	RR JCT BOX	MASTER SWITCH
R64	23	24V	24V	561707	RR JCT BOX	12V EV REFRIGERATOR
R65	23	24V	24V	561707	RR JCT BOX	ENGINE COMPARTMENT LTS

PREVOST

WIRING DIAGRAM

NO: **D060882**

PAGE: **1**

REVISION **03**