

RELAYS NUMBER CODE

No.	PAGE	COIL V	#PREV.	LOCATION	FUNCTION	No.	PAGE	COIL V	#PREV.	LOCATION	FUNCTION
RF1	8	24V	561707	RR JCT BOX	FAN CLUTCH W/RET. SPEED 1	R 80	11.1	24V	561707	RR JCT BOX	ENGINE COMPARTMENT LTS
RF2	8	24V	561707	RR JCT BOX	FAN CLUTCH W/RET. SPEED 2	R 82	19	24V	561707	FR JCT BOX	RETARDER WT
RF3	8	24V	560772	RR JCT BOX	TIME DELAY	R 84	8	24V	561707	RR JCT BOX	FAN CLUTCH-FIRST SPEED
RLA	16	24V	561707	UNDER DASH RH.	ENTRANCE DOOR SEDAN (LATCH)	R 85	8	24V	561707	RR JCT BOX	FAN CLUTCH-SECOND SPEED
RLO	16	24V	561707	UNDER DASH RH.	ENTRANCE DOOR SEDAN (PRESS. SW.)	R 87	19	24V	561707	RR JCT BOX	ENGINE BRAKE REQUEST WT
RLT	16	24V	561707	UNDER DASH RH.	ENTRANCE DOOR SEDAN (LIGHT)	R 89	22	24V	561707	FR JCT BOX	HEATING WINDSHIELD
RLV	16	24V	561707	UNDER DASH RH.	ENTRANCE DOOR SEDAN (VALVE)	R 90	22	24V	561707	FR JCT BOX	HEATING WINDSHIELD
R 1	1.1	24V	561991	FR JCT BOX	ENGINE RUN (24) FR	R 91	22	24V	561707	FR JCT BOX	HEATING WINDSHIELD
R 2	2	24V	561991	BATT. CPT.	ENGINE RUN (12) FR & RR	R 92	22	24V	561707	FR JCT BOX	HEATING WINDSHIELD
R 3	4	24V	561707	BATT. CPT.	FIELD RELAY	R 93	26	24V	561707	RR JCT BOX	PRE-HEAT WATER HEATER (WEBASTO)
R 4	4	24V	561005	BATT. CPT.	STARTING MOTOR	R 94	25	24V	561707	RR JCT BOX	WCL - SYSTEM
R 5	5	24V	561707	FR JCT BOX	CRUISE CTR. STOP SIGN.	R 95	25	24V	561707	RR JCT BOX	WCL - MAGNETIC SW. SIGN.
R 6	9.3	24V	561707	RR JCT BOX	STOP LTS-PARKING BRAKE	R 96	25	24V	561707	RR JCT BOX	WCL - DOOR AJAR ALARM
R 7	5	24V	561707	FR JCT BOX	FAST IDLE	R 97	25	24V	561707	RR JCT BOX	WCL - DOOR AJAR PARK. BRAKE
R 8	6	24V	561707	RR JCT BOX	12V IGNITION WT	R 98	25	12V	561538	RR JCT BOX	WCL -
R 9	9.3	24V	561707	RR JCT BOX	BACK-UP LTS	R 99	8	24V	561707	RR JCT BOX	RADIATOR FAN CLUTCH
R 11	5	24V	561707	RR JCT BOX	12V IGNITION DDEC3	R 100	4	12V	561538	RR JCT BOX	GENERATOR SIGNAL
R 12	7	12V	562092	FR JCT BOX	ELECTRICAL HORNS	R 101	13.1	24V	561707	FR JCT BOX	DAMPER GAZ CYLINDER
R 13	9.3	24V	561707	FR JCT BOX	FOG LTS	R 102	13.1	24V	561707	RR JCT BOX	COMPRESSEUR CLUTCH CUT-OUT BELOW 40 F
R 14	9.1	24V	561707	FR JCT BOX	BLINKER	R 2010	26.2	24V	561230	WEBASTO PRE-HEAT	WEBASTO
R 15	9.1	24V	561707	FR JCT BOX	FR MARKER LTS	V IMN	6	12V	562092	RR JCT BOX	VIM WORLD TR.-NEUTRAL SIGNAL
R 16	9.1	24V	561707	FR JCT BOX	IDENT. & CLEARANCE LTS	V IMR	6	12V	562092	RR JCT BOX	VIM WORLD TR.-BU SIGNAL
R 17	9.1	24V	561707	RR JCT BOX	TAIL,LICENCE,MARKER-RR LTS	V IM1	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 1
R 18	9.1	24V	561707	FR JCT BOX	D R L-PARK BRK CUT-IN	V IM2	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 2 ENG. BRK DISABLE
R 19	9.1	24V	561707	FR JCT BOX	HEADLAMPS (H)	V IM3	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 3 SPD SW. 5MPH NO NO
R 20	9.1	24V	561707	FR JCT BOX	HEADLAMPS (LO)	V IM4	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 4 RETARD. ON SIGNAL
R 21	9.2	24V	561707	FR JCT BOX	L.H. DIRECTIONNAL LT						
R 23	9.2	24V	561707	FR JCT BOX	R.H. DIRECTIONNAL LT						
R 24	9.2	24V	561707	FR JCT BOX	R.H. CORNERING LT						
R 25	9.2	24V	561707	FR JCT BOX	L.H. CORNERING LT						
R 26	9.3	24V	561707	RR JCT BOX	STOP LTS						
R 27	11.2	24V	561707	RR JCT BOX	AISLE & EMERG.EXIT - LTS						
R 28	11.2	24V	561707	FR JCT BOX	DASH LTS RHEOSTAT						
R 29	11.3	24V	561707	RR JCT BOX	READING LTS R.H.						
R 30	11.3	24V	561707	RR JCT BOX	READING LTS L.H.						
R 31	11.3	24V	561707	RR JCT BOX	GENERAL LTS						
R 32	11.4	24V	561707	RR JCT BOX	24V FLUORESCENT						
R 33	13.1	12V	562092	FR JCT BOX	BLOWER CUT-IN RLY						
R 34	13.1	24V	561707	RJB A/C JCT PANEL	A/C LOGIC PANEL						
R 35	13.1	24V	561707	RJB A/C JCT PANEL	WATER PUMP						
R 36	13.1	24V	561707	RJB A/C JCT PANEL	A/C COMPRESSOR CLUTCH						
R 37	10	24V	561707	FR JCT BOX	KNEELING LT						
R 39	13.2	24V	561005	BATT. CPT.	CONDENSER FAN MOTOR						
R 40	13.2	24V	561014	BATT. CPT.	CONDENSER SPEED CTR HI						
R 41	13.2	24V	561005	BATT. CPT.	CONDENSER SPEED CTR HI						
R 43	18	24V	561707	FR JCT BOX	KNEELING SYSTEM						
R 44	18	24V	561707	FR JCT BOX	KNEELING SYSTEM						
R 47	23	24V	561707	GALLEY COMPT	GALLEY-LIQUID CONTAINERS						
R 48	23	24V	561707	GALLEY COMPT	COFFEE MAKER						
R 49	21	24V	561707	FR JCT BOX	ABS - SERVICE BRK RLY						
R 50	21	24V	561707	FR JCT BOX	ABS - VR2 RLY						
R 51	21	24V	561707	FR JCT BOX	ABS - WARNING RLY						
R 52	21	24V	561707	FR JCT BOX	ABS - VR1 RLY						
R 53	1.1	24V	561991	RR JCT BOX	ENGINE RUN (24) RR						
R 54	1.1	24V	561991	BATT. CPT.	12V CUT OUT RLY RR						
R 55	1.1	24V	561991	BATT. CPT.	12V CUT OUT RLY FR						
R 57	9.1	24V	561707	FR JCT BOX	DAYS BLINKER						
R 59	9.3	12V	562092	RR JCT BOX	DOCKING LTS						
R 61	9.3	24V	561707	RR JCT BOX	STOP LTS-JACOB & RET. SIGNAL						
R 66	20.3	24V	561707	SS JCT PANEL	SOUND SYSTEM VIDEO						
R 67	20.1	24V	561707	SS JCT PANEL	SOUND SYSTEM RADIO						
R 68	20.1	24V	561991	SS JCT PANEL	SOUND SYSTEM AMPLIFIER						
R 78	1.1	12V	562092	FR JCT BOX	MASTER SWITCH						
R 79	23	24V	561707	GALLEY CPT.	GALLEY-REFRIGERATOR						