

WIRING DIAGRAM INDEX

Information Pages		Engine Start	3.2	
Multiplexed Devices Index	B1 – B8	Engine ECM	14.1	
Arrangement – Harness	C1	Engine Override	14.1	
Glossary	D	Entrance door	29.1	
Circuit Number Listing	E	Ether Switch	13.1	
Circuit Breaker code	F	Engine bloc heater	11.1	
Connectors code	G	F		
Diode Number Code	H	Fast Idle	14.1	
Resistors Number Code	J	Fire Alarm	9.1	
Fuses Code	L	Flashers	26.1,26.2	
Relay Code	K	Fog lights	26.3	
Functions		Fuel Sender	10.1	
A		Fuel Prime Pump	13.1	
Abs	16.1	Fuel water Filter	13.1	
Automatic Fire Supp. System	40.1	G		
B		Grounds	2.1	
Back-up Camera	28.1	H		
Back-up lights and alarm	26.3	Hazard	26.1	
Battery and Equalizer	1.1	Head Lights	26.1	
Battery Charger	17.1	Horn	9.1	
Brake	12.1	Hvac Defroster	18.1	
C		Hvac Passenger	18.2	
Charging System	3.2	Hvac Driver only	18.3	
Clearance lights rear & front	26.1,26.2	K		
Cluster	10.1	Keyless keypad	29.1	
Converter interface	36.1	L		
Cornering Lights	26.3	Level low	32.1	
Cruise control	14.1	Luggage compt lighting	25.1	
D		Luggage door Lock/Unlock	33.1	
Dash Lights	19.1	Luggage door switches	24.1	
Differential lock	37.1	M		
Docking Lights	26.3	Main Distribution Ignition & Batt.	3.1	
Driver's Light and Backlight	19.1	Main Distribution Wake-Up	3.3	
Driver's Power Window	30.1	Marker Lights	26.1,26.2	
Driver's seat	35.2	Mirror Ramco	31.1	
E		Multiplexing power distribution	7.1	
Engine brake and Retarder	12.1	Multiplexing Network	6.1	
Engine compt lighting	25.1			
		P		
		Park Brake Sensor	12.1	
		Trailer Brake Sensor	12.1	
		Parking Brake Release Switch	32.1	
		Power Distribution FJB	4.1	
		Power Distribution RJB	5.1	
		Power Outlet	30.1	
		Prime Pump	13.1	
		Prodriver	11.1	
		Pneumatic Cut-Out Acc sol	9.1	
		R		
		Radiator Fan Clutch	13.1	
		Rear junction box door fan	11.1	
		S		
		Service Brake Relay	12.1	
		Slide out (1-2)	20.1	
		Slide out (3-4)	20.2	
		Spare Wires	8.1	
		Stop lights	26.2	
		Sun Visor	30.1	
		Steering Control ZF	37.1	
		Steering Multi-functions	38.1	
		T		
		Tag	32.1	
		Tail and Licence Lights	26.2	
		Test Switch	9.1	
		Transmission ECU	15.1-15.2	
		Trailer Package	26.4	
		Tire Pressure Monitor. Sys.	39.1	
		W		
		Window Ajar &Awning	27.1	
		Wiper & Washer	34.1	