

# Wiring diagram pages list

Multiplex outputs	<b>B1</b>	<b>D</b>		Hvac defroster	18.1	<b>R</b>	
Multiplex input	<b>B2</b>	Dash lights	19.1	Hvac passenger	18.2	Reading lamps	22.2
Multiplex Error list	<b>B3</b>	DC/DC Converter 12v	40.2			Rear Tachometer	14.3
Layout vehicle - harness	<b>C1</b>	Destination sign	28.1	<b>I</b>		Retarder	12.1 - 15.1
Pins configuration	<b>D</b>	Driver's light & backlight	19.1	Ignition & Engine Start	3.2	RJB fan	1.1
Circuits list	<b>E</b>	Driver window	30.1	Indirect lighting	23.1		
Circuit breakers list	<b>F</b>			Infotainment	35.3	<b>S</b>	
Connectors list	<b>G</b>	<b>E</b>		IVN Clever Device	35.8-35.9	Snow Chains	16.2
Diodes list	<b>H</b>	ELD Gateway	42.1			Speakers	35.2
Resistors list	<b>J</b>	Emergency & Aisle lights	20.1	<b>K</b>		Stop Request	22.2
Relays list	<b>K</b>	Engine ECU	14.1	Kneeling system&Hi Buoy	32.1	Spares wires	8.1
Fuses list	<b>L</b>	Engine heater	14.1			Stop lights	26.2
Wire identification chart	<b>M</b>	Engine start	3.2	<b>L</b>		Step lights	29.1
		Engine & RJB cmpt. Light	25.1	Luggage compartment Lighting	25.1		
<b>A</b>		Entrance door & lights	29.1			<b>T</b>	
AFSS KIDDE TLSE	38.2	ESP	16.1	<b>M</b>		Tag	32.1
Air dryer	37.1			Main dist. ignition & batt.	3.1	Tail & licence lights	26.2
Air Filter	14.3	<b>F</b>		Markers lights	26.1 - 26.2	Transmission ECU	15.1
Alternators	1.1	Fans radiator	13.1	Mirrors	31.1	Trailer (FR)	26.4
Able Syst	35.8	FareBOX	28.1	Mobile View	35.7		
		Fast idle	14.1	Multiplex power distribution	7.1	<b>U</b>	
<b>B</b>		Fire suppression system	38.1	Multiplex network	6.1 - 6.2	Ultracap	43.1
Back-up warnings	26.3	Flashers	26.1-26.2			Upper defrost	18.4
Batteries & Equalizer	1.1	Fuel gauge	10.1	<b>O</b>		Urea system	14.2
BCIS	35.1			OIL Separator	37.1		
Brake pedal sensor &Interlock	12.1	<b>G</b>				<b>V</b>	
Brake Wear	12.2	Grounds electronic	2.1	<b>P</b>		Volvo link TGW	37.1
		Grounds chassis	2.2	Parcel rack A/C system	18.3		
<b>C</b>				Park brake sensor	12.1	<b>W</b>	
Camera system	35.7	<b>H</b>		Power distribution FJB 12V	4.1	Wet Tank	37.1
Clearance lights	26.1-26.2	Hazard	26.1	Power distribution FJB 24V	4.2	Wheel chair lift Ricon	36.1
Cluster	10.1	Head lights	26.1	Pwr dist. RJB 12V & 24V	5.1	WIFI	35.4
Coolant Level Led	14.3	Horn	9.1	Pwr dist.P.RACK 12V & 24V	5.2	WIF Fuel Filter	14.1
Curb Light	21.1					Wipers & washer	34.1