LUBRICATION AND SERVICING SCHEDULE	Item	Months	DISTANCE TRAVELED[1] (miles/km)																																LUBRICANT &/OR PART[2]
			6 250 / 10 000	12 500 / 20 000	18 750 / 30 000	25 000 / 40 000	31 250 / 50 000	37 500 / 60 000	43 750 / 70 000	50 000 / 80 000	56 250 / 90 000	62 500 / 100 000	68 750 / 110 000	75 000 / 120 000	81 250 / 130 000	87 500 / 140 000	93 750 / 150 000	100 000 / 160 000	106 250 / 170 000	112 500 / 180 000	118 750 / 190 000	125 000 / 200 000	131 250 / 210 000	137 500 / 220 000	143 750 / 230 000	150 000 / 240 000	156250 / 250 000	162 500 / 260 000	168 750 / 270 000	175 000 / 280 000	181 250 / 290 000	187 500 / 300 000	193 750 / 310 000	200 000 / 320 000	
GENERAL																																			
Flexible hoses, thoroughly inspect all hoses	-	12								•								•								•								•	-------
Front discharge tube, qty:2, check to see if clogged [3]	-	3																																	-------
01 ENGINE																																			
Air cleaner, inspect, clean, replace element if required	27	6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	Filter #530197
Engine, change oil and filters. Oil SAE 15W40, API CI-4	17	12		•		•		•		•		•		•		•		•		•		•		•		•		•		•		•		•	Filter #510458
Engine crankcase breather, clean breather steel mesh	23	12								•								•								•								•	-------
03 FUEL																																			
Change primary & secondary fuel filters, fill with clean fuel before installation	28	12		•		•		•		•		•		•		•		•		•		•		•		•		•		•		•		•	Primary #510137 ; prim. w/sep #531390 ; secondary #510128
05 COOLING																																			
Radiator fan drive gearbox,check oil level, add if necessary	20	6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	Mobil SHC 630 #180217
Radiator fan drive gearbox, change oil	20	12								•								•								•								•	Mobil SHC 630 #180217
Coolant filter/Conditioner, replace element	18	12		•		•		•		•		•		•		•		•		•		•		•		•		•		•		•		•	Filter #550630
Coolant surge tank, test coolant solution	21	12		•		•		•		•		•		•		•		•		•		•		•		•		•		•		•		•	-------
Cooling system, drain, flush and refill	18/ 21	24																																•	Engine coolant
06 ELECTRICAL																																			
Battery terminals, clean and coat terminals	30	12																																	Battery terminal coating
Bosch alternators, replace brushes & voltage regulator		24																•																•	Regulator #562981 Brush set #562983
Bosch alternators, replace bearings		48																																•	Bearing, Ball #562972 Bearing, Roller #562976

[1] Proceed to maintenance operation at distance indicated on odometer or specified number of month, whichever comes first.
[2] See paragraph 2.5 & 2.6 of this section for lubricant and part number specifications.
[3] Discharge tubes are rubber tubes located under vehicle

LUBRICATION AND SERVICING SCHEDULE	Item	Months	DISTANCE TRAVELED[1] (miles/km)																																	LUBRICANT &/OR PART[2]
			6 250 / 10 000	12 500 / 20 000	18 750 / 30 000	25 000 / 40 000	31 250 / 50 000	37 500 / 60 000	43 750 / 70 000	50 000 / 80 000	56 250 / 90 000	62 500 / 100 000	68 750 / 110 000	75 000 / 120 000	81 250 / 130 000	87 500 / 140 000	93 750 / 150 000	100 000 / 160 000	106 250 / 170 000	112 500 / 180 000	118 750 / 190 000	125 000 / 200 000	131 250 / 210 000	137 500 / 220 000	143 750 / 230 000	150 000 / 240 000	156250 / 250 000	162 500 / 260 000	168 750 / 270 000	175 000 / 280 000	181 250 / 290 000	187 500 / 300 000	193 750 / 310 000	200 000 / 320 000	250 000 / 400 000	
07 TRANSMISSION																																				
Allison World Automatic transmission equipped with retarder, change oil (standard oil) and filters	16	6		•		•		•		•		•		•		•		•		•		•		•		•		•		•		•		•		Oil Dexron-III/VI
Allison World Automatic transmission without retarder, change oil (standard oil) and filters	16	12				•				•				•				•				•				•				•				•		Oil Dexron-III/VI
Allison World Automatic transmission equipped with retarder, change oil (TranSynd synthetic fluid)	16	24								•								•								•								•		TranSynd Synthetic Fluid
Allison World Automatic transmission with or without retarder, change filters (TranSynd synthetic fluid)	16	24								•								•								•								•		Filters #571709
Allison World Automatic transmission without retarder, change oil (TranSynd synthetic fluid)	16	48																								•										TranSynd Synthetic Fluid
ZF-Astronic Automatic Transmission, change oil & filter after 185 000 miles (300 000 km)	16	24																													•					Castrol Syntrans grade SAE 75W-85
Transmission oil cooler, replace unit if vehicle is equipped with transmission retarder	43	24																																		Prévost #550712
09 PROPELLER SHAFT																																				
Grease one fitting on each universal joint and slip joint	34	6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		Multipurpose grease
11 REAR AXLE																																				
Differential, check oil level, add if necessary	35					•				•				•				•				•				•				•				•		Same type of oil used
Differential, change oil, clean breathers	35	12																•																•		Multigrade gear oil
Differential, change oil, clean breathers	35	48																																	•	Full synthetic gear oil
Tag axle lever pivot, grease one fitting on each pivot	15	6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		Multi purpose grease
12 BRAKE & AIR																																				
Air tanks, drain water from all tanks	7	12		•		•		•		•		•		•		•		•		•		•		•		•		•		•		•		•		-------
Accessories air filter, change filter element	3	24																•																•		Filter element #641340
Air dryer, change cartridge	36	24																•																•		Cartridge #641244 or 641278

[1] Proceed to maintenance operation at distance indicated on odometer or specified number of month, whichever comes first.
[2] See paragraph 2.5 & 2.6 of this section for lubricant and part number specifications.

LUBRICATION AND SERVICING SCHEDULE	Item	Months	DISTANCE TRAVELED[1] (miles/km)																															LUBRICANT &/OR PART[2]
			6 250 / 10 000	12 500 / 20 000	18 750 / 30 000	25 000 / 40 000	31 250 / 50 000	37 500 / 60 000	43 750 / 70 000	50 000 / 80 000	56 250 / 90 000	62 500 / 100 000	68 750 / 110 000	75 000 / 120 000	81 250 / 130 000	87 500 / 140 000	93 750 / 150 000	100 000 / 160 000	106 250 / 170 000	112 500 / 180 000	118 750 / 190 000	125 000 / 200 000	131 250 / 210 000	137 500 / 220 000	143 750 / 230 000	150 000 / 240 000	156250 / 250 000	162 500 / 260 000	168 750 / 270 000	175 000 / 280 000	181 250 / 290 000	187 500 / 300 000	193 750 / 310 000	200 000 / 320 000	
14 STEERING																																		
Drag link ends, grease one fitting at each end	4	6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	Multi purpose grease
Relay rod ends, grease one fitting at each end	36	6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	Multi purpose grease
Steering tie rod ends, grease one fitting at each end	40	6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	Multi purpose grease
Idler arm, grease fitting	41	6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	Multi purpose grease
Bell crank, grease fitting	41	6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	Multi purpose grease
Steering damper cylinder, grease one fitting at rod end	39	6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	Multi purpose grease
Steering knuckle pins, grease two fittings per knuckle	9	6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	Multi purpose grease
Power steering reservoir, replace oil and filter cartridges	29	12								•								•								•							•	Cartridge #660987
16 SUSPENSION																																		
Upper A-Arm Ball Joint, grease fitting	42	6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	Molykote longterm 2/78 grease (preferably) or lithium NLGI no2 or no1
22 HEATING & AIR CONDITIONING																																		
A/C compressor, check oil level, add if necessary	25	6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	Polyolester oil
A/C receiver tank, check refrigerant level, add if necessary	37	6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	HFC 134A
Refrigerant moisture indicator, replace filter dryer unit according to moisture indicator (as needed)	38	6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	Filter #950262
A/C and Heating air filters, clean or replace all elements	10	6		•		•		•		•		•		•		•		•		•		•		•		•		•		•		•		•	Driver #871147 , passenger #871051
Coolant strainer, check, clean, change cartridge if required	11	12								•								•								•							•	Cartridge #871029
Condenser discharge tube, qty:2, check to see if clogged [3]	-	3																																-------
Evaporator discharge tube, qty:6, check to see if clogged [3]	-	3																																-------
Evaporator motor, condenser motor, recirculating pump drive motor, inspect brush, replace if necessary	-	12								•								•								•							•	Refer to parts manual

[1] Proceed to maintenance operation at distance indicated on odometer or specified number of month, whichever comes first.
[2] See paragraph 2.5 & 2.6 of this section for lubricant and part number specifications.