Power distribution Rear Junction box



PREVOST®	WIRING DIAGRAM	No:D061150	Page:5.1	Rev:04