PREVOST | WIRING DIAGRAM | NO: D060976 | PAGE: 3.1 | REVISION 08

CHASSIS GROUND

FRONT JUNCTION BOX COMPARTMENT

FRONT SECTION (FS)

- FRONT SERVICE CPT C105 (B), C106 (B), C239 (B), C260 (A&B), C183 (A)
- FRONT SERVICE CPT C267 (7), C536 (4)
- FRONT SERVICE CPT C323 (1), SH1, SH3
- BEHIND DASH RH PANEL C452 (1), AA2 (85)
- FRONT JCT. BOX - RELAYS & C522 (87)

→ 0-0C-14, 0-0C1-18, 0-0C1-14, 0-0C2-18, 0-0C3-18, 0-0C4-18, C3 (15), 0-0C4-14 → FRONT JCT BOX 0C GROUND STUD

- FRONT SERVICE CPT C435 (2), C246 (3), C242 (3) & STEP LT
- FRONT SERVICE CPT C102 (GRD), C103 (GRD), C104 (GRD), LO BUOY SW & STEP LT
- FRONT SERVICE CPT HEADLAMP CON C243
- FRONT JCT. BOX - CORNERING LTS RESISTORS
- FRONT JCT. BOX - FOG LTS RESISTORS
- LH CONSOLE

→ 0-0L-14, 0-0L1-14, 0-0L2-12, 0-0L3-14, 0-0L4-14, C3 (22), (16), 0-0L3-14, 0-0L4-14, 0-0L5-14, (24) C171 → FRONT JCT BOX 0L GROUND STUD

- WIPER MOTOR C177 (1) & PULSE MOD. C176 (1) & RH MIRROR C269 (3)
- DRIVER'S HTR FAN SPEED CTRL MOD. C175 (5)
- FR. SERV. CPT-HORNS C101 (B), & WASHER PUMP
- RADIATOR FAN CLUTCH SPEED 2 C549
- FR. JCT. BOX - WIPER PULSE MOD. C248 (1)
- LH CONSOLE SWITCH
- FRONT SERVICE CPT - LH MIRROR C268 (3)

→ 0-0M-14, 0-0M3-12, 0-0M4-14, 0-0M5-14, 0-0M6-14, C3 (14), 0-0M6-14, 0-0M7-14, C171 (21), 0-0M7-14, 0-0M7-14 → FRONT JCT BOX 0M GROUND STUD

- FR. SERV. CPT- TAG PRESSURE SW.
- LH SWITCH PANEL
- DASH LH PANEL
- BEHIND DASH PANEL-AUDIBLE FLASHER C424 (1)
- BEHIND DASH PANEL - B/U MONITOR C394 (2)
- CLUSTER
- WIRELESS MIC.CHARGER P.20.5
- FR. JCT BOX - GROUND JCT BLOCK - SHIFTER & DDR CONNECTOR
- STEERING CONTROL ZF P. 15.1
- 12V POWER OUTLET
- HVAC DASH MODULE SEE P. 13.1
- DDR CONNECTOR SEE P5.1

→ 0-0T-18, 0-0T1-18, 0-0T2-18, C3 (23), 0-0T3-14, 0-0T3-14, 0-0T4-16, 0-0T5-14, 0-0T7-14 → FRONT JCT BOX 0T GROUND STUD

FRONT ROOF SECTION (FRS)

- ROOF ACCES. CLEARANCE LTS C213(1), FAN DEFROST C365(1), DEST. SIGN. C364(1) C478(3), WARNING C362(1) C363(1) C373(1), WIPER MOT. C361(1) & DRIVER'S LTS
- HEATING UPPER WINDSHIELD

→ 0-0A-18, 0-0A-18, 0-0A-14, 0-0A-14, 0-0B-12 → FRONT LH ROOF GROUND STUD

REAR JUNCTION BOX COMPARTMENT

REAR SECTION (RS)

- VOLTAGE REGULATOR - C464(E)
- RR JCT. BOX - RELAYS,C136(1),C274(5)(6) R84, R85, C221(2)
- VIMN(87), VIMR(87), VIM4(30)
- RETARDER FAN CLUTCH RF2
- DOCKING LTS RESISTORS
- AISLE LTS C83(1)
- LH READ LTS C207(1), PASS & HOST CHIME SW
- RH READ LTS C206(1), PASS & HOST CHIME SW
- LAV. OCC. LT C143(3), GAL. LT C328(1) FLUOR C41(1)
- WCL RELAY R94,R96,R98,C388(9)
- LUGGAGE CPT WCL PUMP RELAY R55,R54,R2
- RR, LH SIDE MARK. AND FLASH C117,C121
- RR, RH SIDE MARK. AND FLASH C113,C114
- RR END LAMPS RH C119 (A)
- RR END LAMPS LH C120 (A)
- ENG CPT C126(B), C128(2), C129(2), C130(2), C131(2), C422(1)
- ENG CPT C230(2), C127(B), C122(B), C124(A)
- RR ROOF CAMERA C87(1)
- RR ROOF CLEARANCE LTS C87(2) & ENGINE CPT C287(A), C432(2) & C115(B)
- ENG CPT C125(B)
- ZF TANSMISSION MAIN GROUND
- LUG CPT RH SIDE MARKER C103, FLASHER C104
- LUG CPT FUEL TANK C152(A), DAMPER C111(2), WATER VALVE C155(D), BYPASS VALVE C156(B), LH SIDE FLASHER C102, LH SIDE MARKER C103
- GALLEY INVERTER JUNCTION BLOCK
- GALLEY COFFEMAKER
- GALLEY R47 R48 R79, C403 LAMP, SW LT, HEAT CONT

→ 0-0AA-12, 0-0-18, 0-0A-16, P, 0-0B-10, 0-0A-14, 0-0W-18, 0-0R-16, 0-0DR-14, C35 (2), 0-0E-14, Q, (4), 0-0G-14, (15), 0-0H-16, 0-0WC-16, R, 0-0C-10, 0-0W-8, 0-0D-16, 0-0DF-16, C91 (51), 0-0RH-16, (52), 0-0LH-16, 0-0X-12, (55), 0-0P-14, (54), 0-0R-14, 0-0XA-12, (53), 0-0J-16, 0-0Y-12, (57), 0-0K-14, (56), 0-0N-14, 0-0YA-12, 0-0Z0-14, C52 (21), 0-0B-14, 0-0Z-12, (20), 0-0A-14, 0-0Z-12, 0-0-6, 0-0-10, 0-0-16 → BATTERY COMPARTMENT GROUND STUD; 0-0B1-2

LAVATORY WALL (LW)

- HAT RACK C577,C578
- HAT RACK C575,C576
- HAT RACK C56
- HAT RACK C57

→ 0-0D-12, 0-0F-12, 0-0J-10, 0-0K-10 → LAVATORY WALL GROUND STUD

EVAP. COMPT. (EC)

- CONDENSER FAN SPEED. RLY R39, R40, R41 P. 13.4
- CONDENSER FAN RELAY P. 13.4
- CONDENSER FAN LH P. 13.4
- EVAP. FAN P. 13.4

→ 0-0C-16, 0-0D-10, 0-0D-10, 0-0-1 → EVAP. COMPARTMENT GROUND STUD

RR JCT BOX (RBG)

- WORLD TRANS. ACCES. BAT. GRD SEE PAGE 6.1

0-143W-12, S, 0-00-12, 0-00-12 → FROM BATTERY COMPARTMENT ELECTRONIC GROUND JCT BLOCK SEE PAGE 1.1

FR JCT BOX (FBG)

- TELL TALE LIGHT MODULE SEE PAGE 28.1
- CLUSTER SEE P.7.1
- WIRELESS MIC. CHARGER P. 20.5

C74 (36), 0-00A-18, 0-00-16

BATTERY GROUND