Power distribution Rear Junction box



PREVOST®	WIRING DIAGRAM	No:D061020	Page:5.1	Rev:9