LAZER FORMAT TA CHELLE 8.2

CONNECTORS CODE ID  Page G-1

| No. | LOCATION | #ND TYPE | *PIN CAVITY | *SOCKET HOUSING | HOUSING |
|---|---|---|---|---|---|
| C1 | FR JCT BDI COMPARTMENT | AMP CPC | 37 | 560644 | 560646 |
| C2 | FR JCT BDI COMPARTMENT | AMP CPC | 24 | 560641 | 560643 |
| C3 | FR JCT BDI COMPARTMENT | AMP CPC | 37 | 560714 | 560713 |
| C4 | FR JCT BDI COMPARTMENT | AMP CPC | 16 | 560493 | 560495 |
| C5 | FR SERVICE COMPT.-UNDERHEATH | AMP CPC | 37 | 560644 | 560646 |
| C6 | FR SERVICE COMPT.-UNDERHEATH | AMP CPC | 24 | 560641 | 560643 |
| C7 | FR JCT BDI COMPT.-UNDERHEATH | AMP CPC | 37 | 560714 | 560766 |
| C8 | FR SERVICE COMPT.-UNDERHEATH | AMP CPC | 37 | 560714 | 560713 |
| C9 | ALARM JCT BDI | AMP CPC | 37 | 560644 | 560646 |
| C10 | ALARM JCT BDI | AMP CPC | 37 | 560644 | 560646 |
| C11 | FR SERVICE COMPARTMENT | AMP CPC | 24 | 560642 | 560643 |
| C12 | FR SERVICE COMPARTMENT | AMP CPC | 24 | 560642 | 560643 |
| C13 | LH CONSOLE-HEATER MOR. | AMP HNL | 2 | 561248 | 562247 |
| C13 | FR SERVICE COMPT. | AMP HNL | 3 | 560562 | 560565 |
| C13 | LH CONSOLE-CTR HORROR | AMP HNL | 6 | 561552 | 561555 |
| C14 | UNDER DASH-LH HORROR | AMP HNL | 6 | 561552 | 561555 |
| C15 | RR JCT BDI | AMP CPC | 24 | 560640 | 560643 |
| C16 | UNDER DASH-RH HORROR | AMP HNL | 6 | 561552 | 561555 |
| C16 | LH CONSOLE SW-CRUISE ON-OFF | SWF | 8 | ------ | 561087 |
| C17 | LH CONSOLE SW-CRUISE RESUME | SWF | 8 | ------ | 561087 |
| C18 | LH CONSOLE SW-CRUISE SET | SWF | 8 | ------ | 561087 |
| C20 | RR JCT BDI | AMP CPC | 37 | 560644 | 560646 |
| C21 | RR JCT BDI | AMP CPC | 24 | 560641 | 560643 |
| C26 | HYD & HAN TRANSM.-NEUT.& B-U | PED WP | 4 | 561610 | 561611 |
| C27 | HYD & HAN TRANSM.-SPEED SENS. | PED WP | 2 | 561566 | 561569 |
| C30 | DDEC ENGINE-ECM | PED | 30 | ------ | 561600 |
| C35 | RR JCT BDI | AMP CPC | 24 | 560642 | 560643 |
| C36 | EMERGENCY-EXIT LTS | AMP HNL | 2 | 560800 | 560898 |
| C37 | RR SECTION-LH HAT RACK | AMP HNL | 9 | 560661 | 561662 |
| C38 | RR SECTION-RH HAT RACK | AMP HNL | 9 | 560661 | 561662 |
| C40 | RR JCT BDI | AMP CPC | 16 | 560493 | 560494 |
| C41 | LAVATORY-ROOF FLOORS CONT. | AMP HNL | 2 | 560800 | 560898 |
| C42 | LAVATORY-BACK WALL-WTR TANK | AMP HNL | 2 | 560800 | 560898 |
| C43 | LAVATORY-BACK WALL-ACCESS. | AMP HNL | 9 | 560661 | 561662 |
| C45 | ALARM JCT BDI COMPARTMENT | AMP CPC | 24 | 560642 | 560643 |
| C46 | FR SERVICE COMPT.-UNDERHEATH | AMP CPC | 37 | 560714 | 560713 |
| C49 | BATTERY COMPT.-LOW BLOCK | AMP HNL | 2 | 560800 | 560898 |
| C50 | FR SERVICE COMPT.-LOW BLOCK | PED WP | 11 | 560585 | 561157 |
| C52 | RR JCT BDI | AMP CPC | 22 | 560718 | 560719 |
| C53 | RR JCT BDI | AMP CPC | 14 | 560585 | 560584 |
| C54 | UNDER DASH-LH UNIT | HNL | 6 | 561552 | 561555 |
| C55 | UNDER DASH-RH SW PANEL | AMP CPC | 9 | 560636 | 560637 |
| C56 | UNDER DASH-RH CONSOLE | AMP CPC | 24 | 560642 | 560643 |
| C57 | UNDER DASH-RH ACCESSORIES | AMP CPC | 22 | 560695 | 560718 |
| C58 | UNDER DASH-RH ACCESSORIES | AMP CPC | 22 | 560695 | 560718 |
| C59 | EVAPORATOR COMPARTMENT | AMP HNL | 2 | 560800 | 560898 |
| C60 | RR JCT BDI COMPT.-L/T | AMP HNL | 2 | 561248 | 562247 |
| C61 | LUGGAGE COMPARTMENT LTS | AMP HNL | 2 | 561248 | 562247 |
| C62 | LUGGAGE COMPARTMENT LTS | AMP HNL | 2 | 561248 | 562247 |
| C63 | LUGGAGE COMPARTMENT LTS | AMP HNL | 2 | 561248 | 562247 |
| C64 | LUGGAGE COMPARTMENT LTS | AMP HNL | 2 | 561248 | 562247 |
| C65 | LUGGAGE COMPARTMENT LTS | AMP HNL | 2 | 561248 | 562247 |

CONNECTORS CODE ID  Page G-1

| No. | LOCATION | #ND TYPE | *PIN CAVITY | *SOCKET HOUSING | HOUSING |
|---|---|---|---|---|---|
| C66 | LUGGAGE COMPARTMENT LTS | AMP HNL | 2 | 561248 | 562247 |
| C67 | LUGGAGE COMPARTMENT LTS | AMP HNL | 2 | 561248 | 562247 |
| C68 | LUGGAGE COMPARTMENT LTS | AMP HNL | 2 | 561248 | 562247 |
| C69 | RH AXLE ACC-DISPOSE PVC END | PED WP | 6 | 561568 | 561578 |
| C70 | ALARM JCT BDI COMPARTMENT | AMP CPC | 24 | 560642 | 560643 |
| C71 | UNDER INSTRUMENT PANEL-LH | AMP CPC | 37 | 560645 | 560646 |
| C72 | UNDER INSTRUMENT PANEL-CENT. | AMP CPC | 37 | 560645 | 560646 |
| C73 | UNDER INSTRUMENT PANEL-CENT. | AMP CPC | 16 | 560639 | 560640 |
| C74 | ALARM JCT BDI COMPARTMENT | AMP CPC | 24 | 560642 | 560643 |
| C75 | ALARM JCT BDI COMPARTMENT | PED WP | 4 | 561610 | 561611 |
| C76 | LUGGAGE COMPT.-AIR RET.SENS. | AMP HNL | 2 | 561248 | 562247 |
| C77 | LUGGAGE COMPT.-AIR RET.SENS. | AMP HNL | 2 | 561248 | 562247 |
| C78 | FR JCT BDI COMPARTMENT | AMP CPC | 22 | 561791 | 561718 |
| C79 | FR SERVICE COMPT.-UNDERHEATH | AMP CPC | 37 | 560644 | 560646 |
| C80 | LUGGAGE COMPT.-AIR RET.SENS. | AMP HNL | 2 | 561248 | 562247 |
| C81 | PASSENGER COMPT.-HOLE L/T | HNL | 6 | 562078 | 562069 |
| C82 | ENTRANCE DOOR | HOLEX | 6 | 562078 | 562069 |
| C83 | ENTRANCE DOOR-PRESSURE SW. | PED WP | 2 | 561566 | 561569 |
| C84 | ENTRANCE DOOR-PRESSURE SW. | PED WP | 2 | 561566 | 561569 |
| C85 | UNDER INSTRUMENT PANEL-LH | AMP HTA-100 | B | ------ | 562248 |
| C87 | RR SWITL & RR JUSCPT-DRIVER | AMP CPC | 9 | 560636 | 560637 |
| C88 | RR END ROOF-CLEARANCE LTS | AMP HNL | 2 | 560800 | 560898 |
| C89 | RR END ROOF-B-U HONITOR | AMP CPC | 14 | 560582 | 560581 |
| C90 | RR JCT BDI | AMP CPC | 15 | 561787 | 561786 |
| C91 | RR JCT BDI | AMP CPC | 37 | 560566 | 560569 |
| C92 | RR JCT BDI COMPT.-WATI SKID | AMP CPC | 9 | 560635 | 560637 |
| C93 | RR JCT BDI COMPT.-WATI SKID | AMP CPC | 9 | 560635 | 560637 |
| C94 | FR AXLE-ACCESSORIES | AMP CPC | 14 | 560585 | 560581 |
| C97 | RH AXLE ACC-DISPOS PVC END | PED WP | 6 | 561568 | 561578 |
| C98 | FR SERVICE COMPT.-ELC.F.SPEDAL | PED WP | 3 | 561782 | 561781 |
| C99 | FR SERVICE COMPT.-LTS | AMP HNL | 2 | 562248 | 562247 |
| C100 | FR SERVICE COMPT.-CONNECTING | AMP HNL | 2 | 560800 | 560898 |
| C101 | FR SERVICE COMPT.-ELEC.-HORNS | PED WP | 2 | 561566 | 561569 |
| C102 | FR SERV.-WATER-LEVEL-SENS. | HNL | 9 | 560661 | 561662 |
| C103 | FR SERV.& SERV.COMPT.-WIPERS | ITT SS | 2 | 561813 | 561812 |
| C104 | FR SERVICE COMPT.-CLS.& WLKT. | PED WP | 2 | 561566 | 561569 |
| C105 | FR SERVICE COMPT.-CLS.& WLKT. | PED WP | 2 | 561566 | 561569 |
| C106 | FR SERVICE COMPT.-WATER VALVE | PED WP | 2 | 561566 | 561569 |
| C107 | FR SERVICE COMPT.-DUMPER | PED WP | 2 | 561566 | 561569 |
| C108 | FR SERVICE COMPT.-KNEEL.SYS | PED WP | 2 | 561566 | 561569 |
| C109 | FR SERVICE COMPT.-KNEEL.SYS | PED WP | 2 | 561566 | 561569 |
| C110 | FR SERVICE COMPT.-KNEEL.SYS | PED WP | 2 | 561566 | 561569 |
| C111 | EVAPORATOR COMPT.-DAMPER | ITT SS | 2 | 561813 | 561812 |
| C113 | BATT.& RR JUSCPT.-MARKER L/T | ITT SS | 2 | 561813 | 561812 |
| C114 | BATT.& RR JUSCPT.-MARKER L/T | ITT SS | 2 | 561813 | 561812 |
| C115 | ENGINE COMPT.-LTS | PED WP | 2 | 561566 | 561569 |
| C116 | ENGINE COMPT.-LUBRICATOR PUMP | TC | 2 | 561268 | 562997 |
| C117 | UNDER DASH-RH WIPER MOTOR | AMP FF | 6 | ------ | 561186 |
| C118 | UNDER DASH-RH L/H FAN | TC | 2 | 561268 | 562997 |
| C119 | UNDER DASH-RH RH FAN | TC | 2 | 561268 | 562997 |
| C120 | RR JCT BDI-COOLER-CONTROL | AMP HNL | 2 | 561248 | 562247 |
| C121 | RR JCT BDI COMPT.-AT KYH | AMP CPC | 16 | 560639 | 560640 |
| C122 | RR JCT BDI COMPT.-AT KYH | AMP CPC | 16 | 560639 | 560640 |
| C123 | FR SERVICE COMPT.-KNEELING | ITT SS | 3 | 561811 | 561880 |
| C124 | BATTERY COMPT.-DOOR SW.L.T.H | ITT SS | 2 | 561813 | 561812 |
| C125 | RR JCT BDI-COMPT.-DOOR VALVE | PED WP | 2 | 561566 | 561569 |
| C126 | ENGINE CPT-ECM | PED WP | 2 | 561566 | 561569 |

CONNECTORS CODE ID  Page G-2

| No. | LOCATION | #ND TYPE | *PIN CAVITY | *SOCKET HOUSING | HOUSING |
|---|---|---|---|---|---|
| C125 | ENGINE CPT-B-U ALARM | PED WP | 2 | 561566 | 561569 |
| C126 | ENGINE CPT-FLUSHING PUMP | PED WP | 2 | 561566 | 561569 |
| C127 | ENGINE CPT-FUEL FILTER | PED WP | 2 | 561566 | 561569 |
| C128 | ENGINE CPT-A/C COMPRESSOR | ITT SS | 2 | 561813 | 561812 |
| C129 | ENGINE CPT-LUBRICATOR | AMP CPC | 16 | 560639 | 560640 |
| C130 | ENGINE CPT-UNLOADER | ITT SS | 2 | 561813 | 561812 |
| C131 | ENGINE CPT-RH DOOR-SOL.1 | PED WP | 2 | 561566 | 561569 |
| C132 | ENGINE CPT-W/C L.O.PRESS SW | PED WP | 2 | 561566 | 561569 |
| C133 | ENGINE CPT-W/C L.O.PRESS SW | PED WP | 2 | 561566 | 561569 |
| C134 | ALARM JCT BDI COMPARTMENT | PED WP | 4 | 561610 | 561611 |
| C136 | FR JCT BDI-LUGGAGE DOOR CONS. | AMP HNL | 15 | 561787 | 561786 |
| C137 | A/C JCT BDI | AMP CPC | 16 | 560639 | 560640 |
| C138 | A/C JCT BDI-TRANSMITTER | AMP HNL | 2 | 560800 | 560898 |
| C138 | A/C JCT BDI-CONTROL MODULE | AMP HNL | 2 | 560800 | 560898 |
| C139 | A/C JCT BDI-L-DOOC MODULE | AMP HOP | 15 | 562811 | ------ |
| C142 | LAVATORY-DOOR WALL | HNL | 2 | 562248 | 562247 |
| C143 | LAVATORY-DOOR WALL | AMP HNL | 3 | 560800 | 560898 |
| C200 | RH HAT RACK-RH SIDE L.T.S | AMP HNL | 9 | 560661 | 561662 |
| C203 | RH HAT RACK-BALLAST | AMP HNL | 9 | 560661 | 561662 |
| C204 | RH HAT RACK-GENERAL L.T | AMP HNL | 9 | 560661 | 561662 |
| C205 | RH SECT.-RH HAT RACK SPEAKER | AMP HNL | 9 | 560661 | 561662 |
| C206 | RH HAT RACK-READING L.T | AMP HNL | 2 | 562248 | 562247 |
| C207 | RH HAT RACK-READING L.T | AMP HNL | 2 | 562248 | 562247 |
| C208 | LH HAT RACK-BALLAST | AMP HNL | 4 | 560851 | 560852 |
| C210 | RR SECT.-LH HAT RACK SPEAKER | AMP HNL | 9 | 560661 | 561662 |
| C211 | FR SIDE-STORE LH | AMP HNL | 2 | 560800 | 560898 |
| C212 | FR SIDE-STORE LH | AMP HNL | 2 | 560800 | 560898 |
| C213 | FR ROOF-CLEARANCE L.T | AMP HNL | 2 | 560800 | 560898 |
| C216 | UNDER DASH-LH-P.A. | AMP HNL | 9 | 560636 | 560637 |
| C217 | UNDER DASH-LH-P.A. | AMP HNL | 3 | ------ | 561558 |
| C218 | UNDER DASH-LH-P.A. | AMP HNL | 3 | ------ | 561558 |
| C219 | UNDER DASH-LH-P.A. | AMP HNL | 3 | ------ | 561558 |
| C220 | INJECT.SUB-L.FUEL PRIME PUMP | TC | 1 | 561818 | 561873 |
| C222 | ALARM JCT BDI-CONT.-WATER | AMP HNL | 9 | 560661 | 561662 |
| C223 | ALARM JCT BDI-CNT.-DRSW.SPK. | AMP HNL | 9 | 560661 | 561662 |
| C224 | WATER COMPT.-LOW LEVEL SENS. | AMP HNL | 9 | 560661 | 561662 |
| C227 | RH SW.PANEL-SPEAKER | AMP HNL | 9 | 560636 | 560637 |
| C228 | RH SW.PANEL-HIGRO.OUTLET | HOLEX | 4 | 561477 | 561476 |
| C229 | ENGINE CPT-PH.SW.FUEL | DEUTSCH | 2 | 561477 | 561476 |
| C230 | ENGINE CPT-FUEL PRIME PUMP FEED | DEUTSCH | 2 | 562498 | 562495 |
| C231 | ENGINE CPT-FUEL PRIME PUMP | PED WP | 2 | 561566 | 561569 |
| C232 | ENGINE CPT-FUEL PRIME PUMP | PED WP | 2 | 561566 | 561569 |
| C233 | INSTRUMENT PANEL CENTER | HOLEX | 4 | 561477 | 561476 |
| C234 | INSTRUMENT PANEL CENTER | HOLEX | 4 | 561477 | 561476 |
| C235 | UNDER DASH-LH-JACOB CLUTCH | ITT SS | 3 | 561811 | 561880 |
| C236 | UNDER DASH-LH-JACOB CLUTCH | ITT SS | 3 | 561811 | 561880 |
| C237 | UNDER DASH-LH-JACOB CLUTCH | ITT SS | 3 | 561811 | 561880 |
| C238 | A/C JCT BDI-DOOR CONNECTOR | AMP HNL | 9 | 560636 | 560637 |
| C239 | FR SERVICE CPT-HI BUZZ VALVE | PED WP | 2 | 561566 | 561569 |
| C240 | FR SERVICE CPT-KNEEL PRSD SW | PED WP | 2 | 561566 | 561569 |
| C241 | FR SERVICE CPT-FOG RESISTOR | AMP CPC | 3 | 561847 | 561862 |
| C242 | FR SERVICE CPT-FOG RESISTOR | AMP CPC | 3 | 561847 | 561862 |
| C243 | FR SERVICE CPT-HEADLAMPS | TC | 1 | ------ | 561873 |
| C244 | FR SERVICE CPT-RH FOG LAMP | ITT SS | 2 | 561813 | 561812 |
| C245 | FR SERVICE CPT-RH FOG LAMP | ITT SS | 2 | 561813 | 561812 |
| C246 | FR SERVICE CPT-HARN.& DIR.L.T | ITT SS | 3 | 561811 | 561880 |
| C248 | ALARM JCT BDI-WIPER PULSE GEN | AMP FF | 6 | ------ | 561189 |
| C249 | ALARM JCT BDI-CONN.12V TO 5V | AMP HNL | 3 | 561667 | 561550 |

CONNECTORS CODE ID  Page G-3

| No. | LOCATION | #ND TYPE | *PIN CAVITY | *SOCKET HOUSING | HOUSING |
|---|---|---|---|---|---|
| C250 | ALARM JCT BDI-DASH LTS REGUL. | AMP HNL | 4 | 561952 | 561515 |
| C251 | LH SW.PANEL-FAST IDLE | SWF | 8 | ------ | 561087 |
| C252 | LH SW.PANEL-SWITCH L.T | SWF | 2 | ------ | 561837 |
| C253 | LH SW.PANEL-ETHER | SWF | 2 | ------ | 561837 |
| C254 | INST.PANEL-RH ENTR.DOOR SW. | TORRI | 5 | ------ | 562108 |
| C255 | LH SW.PANEL-ESS.SW.L.T | SWF | 2 | ------ | 561837 |
| C257 | INSTRUMENT PANEL CENT-SPEEDO | AMP HNL | 4 | 560851 | 560852 |
| C258 | LH SW.PANEL-MULTI FUNC. SW | SWF | 8 | ------ | 561087 |
| C259 | LH SW.PANEL-MULTI FUNC. SW | AMP FF | 6 | ------ | 561186 |
| C260 | UNDER DASH-RH DOOR-MODULE | AMP HNL | 4 | 561951 | 561668 |
| C261 | UNDER DASH-RH DOOR-MODULE | AMP HNL | 4 | 561951 | 561668 |
| C262 | UNDER DASH-RH DOOR MODULE | AMP HNL | 4 | 561951 | 561668 |
| C263 | UNDER DASH-RH DOOR MODULE | AMP HNL | 3 | 561667 | 561558 |
| C264 | UNDER DASH-RH DOOR MODULE | AMP HNL | 3 | 561667 | 561558 |
| C265 | UNDER DASH-RH DOOR MODULE | AMP HNL | 3 | 561667 | 561558 |
| C267 | UNDER DASH-RH | AMP CPC | 24 | 560642 | 560643 |
| C268 | UNDER DASH-LH-HORROR | HOLEX | 4 | 561552 | 561555 |
| C269 | UNDER DASH-RH HORROR | HOLEX | 4 | 561552 | 561555 |
| C270 | RH SW.PANEL-SPEAKER | AMP HNL | 9 | 560636 | 560637 |
| C271 | RH HORROR POST | HOLEX | 6 | 562248 | 562247 |
| C272 | LH HORROR | SPARTAN | 6 | 560558 | ------ |
| C273 | RH HORROR | SPARTAN | 6 | 560558 | ------ |
| C274 | RADIO | AMP HNL | 9 | 561667 | 561669 |
| C275 | UNDER DASH-RH-DOOR CONT. | AMP HNL | 2 | 560800 | 560898 |
| C276 | UNDER DASH-RH-LOCK SOL.W/LVE | AMP HNL | 2 | 562148 | 562147 |
| C280 | RH SW.PANEL-LH-P.A. | AMP HNL | 9 | 560636 | 560637 |
| C281 | ENGINE COMPT-L.T.S.SW | PED WP | 2 | 561566 | 561569 |
| C282 | ENGINE COMPT-L.T.S.SW | PED WP | 2 | 561566 | 561569 |
| C283 | RH SW.PANEL-SWITCH L.T | SWF | 2 | ------ | 561837 |
| C284 | LH CONSOLE COMPT.-VIDEO SYST. | AMP HNL | 4 | 561671 | 561669 |
| C285 | INSTRUMENT PANEL-RH-CTS | AMP HNL | 2 | 562148 | 562147 |
| C287 | INSTRUMENT PANEL-RH-LTS | AMP HNL | 2 | 562148 | 562147 |
| C288 | RH SW.PANEL-SWITCH L.T | SWF | 2 | ------ | 561837 |
| C289 | LH DASH-CTR-WIPER MOTOR | AMP FF | 6 | ------ | 561186 |
| C290 | RH ROOF-WATCH-YOUR STEP L.T | AMP HNL | 2 | 562148 | 562147 |
| C294 | RH ROOF-SWITCH L.T | AMP HNL | 3 | 561667 | 561558 |
| C295 | FR ROOF-UP WINDSHIELD DEFROST | AMP HNL | 3 | 561667 | 561558 |
| C296 | RH CONSOL-SW.L.T | AMP HNL | 3 | 561667 | 561558 |
| C300 | INSTRUMENT PANEL CENT-TACO | AMP HNL | 4 | 560851 | 560852 |
| C301 | INSTRUMENT PANEL-CENT-SIGN | AMP HNL | 4 | 560851 | 560852 |
| C306 | GALLEY | AMP HNL | 9 | 561661 | 561662 |
| C307 | GALLEY-SW.-PHEDISTAT | AMP HNL | 3 | 561667 | 561669 |
| C309 | DDEC ENGINE-ECM POWER CONS. | PED HP | 5 | ------ | 562345 |
| C310 | LH CONSOL-SW.VIDEO & PAS CHIME | SWF | 8 | ------ | 561087 |
| C311 | LH CONSOL-SW.VIDEO & PAS CHIME | SWF | 8 | ------ | 561087 |
| C312 | LH CONSOL-SW.CEN & FLOOR LTS | SWF | 8 | ------ | 561087 |
| C313 | LH CONSOL-SW.CEN & FLOOR LTS | SWF | 8 | ------ | 561087 |
| C314 | LH CONSOL-SW.WINDOW LTS | SWF | 8 | ------ | 561087 |
| C315 | LH CONSOL-SW.WINDOW LTS | SWF | 8 | ------ | 561087 |
| C316 | LH CONSOL-SPARE SWITCH | SWF | 8 | ------ | 561087 |
| C317 | LH CONSOL-SPARE SWITCH | SWF | 8 | ------ | 561087 |
| C318 | LH CONSOL-SW.DRV WINDOW LIFT | SWF | 8 | ------ | 561087 |
| C320 | LH CONSOL-SW.DRIVER'S LTS | SWF | 8 | ------ | 561087 |
| C321 | LH CONSOL-SW.WIND LIFT HOT. | PED PO | 2 | ------ | 561848 |
| C322 | LH CONSOL-SW.CTR.DAN.WARN. | SWF | 8 | ------ | 561087 |
| C324 | GALLEY-REFRIGERATOR | AMP HNL | 2 | 562147 | 562148 |
| C325 | LH CONSOLE-SW.WIND.LIFT | SWF | 8 | ------ | 561087 |
| C326 | LH CONSOLE-SW.SPARE | SWF | 8 | ------ | 561087 |
| C327 | ENGINE COMPT-MR-START SW.BOY | DEUTSCH | 5 | 562565 | 562566 |

CONNECTORS CODE ID  Page G-3

| No. | LOCATION | #ND TYPE | *PIN CAVITY | *SOCKET HOUSING | HOUSING |
|---|---|---|---|---|---|
| C328 | GALLEY-LAMP | AMP HNL | 2 | 562148 | 562147 |
| C329 | ENGINE TACHO SIGNAL | PED WP | 2 | 561566 | 561569 |
| C330 | GALLEY-MICROWAVE SW.L.T | SWF | 2 | ------ | 561837 |
| C331 | GALLEY-MICROWAVE SW | SWF | 2 | ------ | 561837 |
| C332 | GALLEY-RH CONTAINER SW.L.T | SWF | 8 | ------ | 561087 |
| C333 | GALLEY-RH CONTAINER SW.L.T | SWF | 8 | ------ | 561087 |
| C334 | GALLEY-LH CONTAINER SW | SWF | 8 | ------ | 561087 |
| C335 | GALLEY-LH CONTAINER SW.L.T | SWF | 8 | ------ | 561087 |
| C337 | INSTR.PANEL-LH-UP WIPER SW | SWF | 8 | ------ | 561087 |
| C338 | INSTR.PANEL-LH-UP WIPER SW | SWF | 8 | ------ | 561087 |
| C339 | UNDER DASH-DOOR-MODULE | AMP HNL | 4 | 561951 | 561668 |
| C340 | ALARM JCT BDI-COMP. | AMP HNL | 2 | 560800 | 560898 |
| C341 | INSTR.PANEL-LH-HORNS SW | SWF | 8 | ------ | 561087 |
| C342 | INSTR.PANEL-LH-HEADLAMP SW | SWF | 8 | ------ | 561087 |
| C343 | INSTR.PANEL-LH-FOG L.T SW | SWF | 8 | ------ | 561087 |
| C344 | INSTR.PANEL-LH-FOG L.T SW | SWF | 8 | ------ | 561087 |
| C345 | INSTR.PANEL-LH-DASHLT SW | SWF | 8 | ------ | 561087 |
| C346 | INSTR.PANEL-LH-DASHLT SW | SWF | 8 | ------ | 561087 |
| C347 | INSTR.PANEL-LH-DASHLT SW | AMP HNL | 2 | 560800 | 560898 |
| C348 | ALARM JCT BDI-COMP. | AMP HNL | 2 | 560800 | 560898 |
| C349 | RH CONSOL-RELEUCEDOOR | AMP HNL | 2 | 562148 | 562147 |
| C350 | RH CONSOLE-THERMOMETER | AMP HNL | 3 | 561667 | 561558 |
| C351 | LH HAT RACK-FLOOR LTS | HOLEX | 4 | 561477 | 561476 |
| C352 | RH CONSOLE-CEN TEMP SENSOR | BURNDY | 4 | 561184 | ------ |
| C353 | INSTR.PANEL RH-ONY FAN RHEOST | AMP HNL | 5 | 561552 | 561555 |
| C354 | INSTR.PANEL RH-ONY TEMP CTR | AMP HNL | 5 | 561552 | 561555 |
| C355 | INSTR.PANEL RH-FRT TEMP CTR | AMP HNL | 5 | 561667 | 561558 |
| C357 | INSTR.PANEL RH-WATER TEMP SW | AMP HNL | 3 | 561667 | 561558 |
| C358 | INSTR.PANEL RH-ONY FAN SW | AMP HNL | 3 | 561667 | 561558 |
| C359 | INSTR.PANEL CENT-TAC & SPEED | AMP HNL | 2 | 560800 | 560898 |
| C361 | FR ROOF-WIPER MOTOR | AMP FF | 6 | ------ | 561186 |
| C362 | LH CONSOLE-SW.CENTER OCCUPIED | AMP HNL | 2 | 562148 | 562147 |
| C363 | INSTRUMENT PANEL RH-LTS | AMP HNL | 2 | 562148 | 562147 |
| C364 | RH ROOF-SWITCH L.T | AMP HNL | 3 | 561667 | 561558 |
| C365 | FR ROOF-UP WINDSHIELD DEFROST | AMP HNL | 3 | 561667 | 561558 |
| C366 | RH CONSOL-SW.L.T | AMP HNL | 3 | 561667 | 561558 |
| C368 | CONSOLE-DEF.COL.T SENSOR PED | AMP HNL | 2 | 561566 | 561569 |
| C369 | FR ROOF-DEST.SIGN OPER.SW. | TORRI | 5 | ------ | 562108 |
| C370 | FR ROOF-DEST.SIGN OPER.SW. | TORRI | 5 | ------ | 562108 |
| C371 | FR ROOF-DEST.SIGN FLUORS. | AMP HNL | 2 | 560800 | 560898 |
| C372 | FR ROOF-DEST.SIGN SPEED SW | HOLEX | 4 | 561477 | 561476 |
| C374 | ALARM JCT BDI COMPT-MASTER SW | AMP HNL | 6 | 561552 | 561555 |
| C375 | ALARM JCT BDI COMPT-LH CONSOL | AMP HNL | 6 | 561552 | 561555 |
| C376 | ALARM JCT BDI COMPT-LH CONS. | AMP CPC | 37 | 560714 | 560713 |
| C377 | LH SW.PANEL-STOP ENGOVERIDE | SWF | 8 | ------ | 561087 |
| C378 | LH SW.PANEL-STOP ENGOVERIDE | SWF | 8 | ------ | 561087 |
| C379 | ALARM JCT BDI-MIC W/ SWITCH | AMP HNL | 2 | 562148 | 562147 |
| C380 | FR SERV.COMPT-UNDERHEATH.LTS | AMP HNL | 9 | 560661 | 561662 |
| C381 | LH CONSOLE-W/C POWER SYSTEM | SWF | 8 | ------ | 561087 |
| C387 | RR JCT BDI-W/C | AMP HNL | 9 | 560661 | 561662 |

CONNECTORS CODE ID  Page G-2

| No. | LOCATION | #ND TYPE | *PIN CAVITY | *SOCKET HOUSING | HOUSING |
|---|---|---|---|---|---|
| C388 | RR JCT BDI-WCL/ | AMP HNL | 12 | 561735 | 561734 |
| C389 | WCL REAR DOOR | HOLEX | 4 | 561477 | 561476 |
| C390 | LAVATORY-WALL-WCL REMOTE CTR | SWF | 8 | ------ | 561087 |
| C391 | LAVATORY-WALL-WCL/LAMP | SWF | 8 | ------ | 561087 |
| C392 | LAVATORY-WALL-WCL SW.L.T. | SWF | 8 | ------ | 561087 |
| C393 | LAVATORY-WALL-WCL REMOTE STS. | AMP CPC | 4 | 561686 | 561687 |
| C394 | UNDER INSTRUMENT PANEL-LH | AMP HNL | 4 | 560851 | 560852 |
| C395 | DRIVER'S COMPT.-B-U MONITOR | AMP | 5 | ------ | 562465 |
| C396 | FR SERV.COMPT.-CENTRAL LTS | AMP HNL | 2 | 560800 | 560898 |
| C397 | ENGINE COMPT.-CENTRAL LTS | HOLEX | 6 | 562078 | 562069 |
| C398 | FR SECT.LH HAT RACK-AMPL1 | HOLEX | 6 | ------ | 562464 |
| C399 | FR SECT.LH HAT RACK-AMPL2 | HOLEX | 6 | ------ | 562464 |
| C400 | ENGINE COMPT.-BLOCK HEATER | PED HP | 3 | 561781 | 561782 |
| C401 | FR SECT.LH HAT RACK-AMPL1 | HOLEX | 6 | ------ | 562464 |
| C402 | RR DRIVE AXLE-AIR DRYER | PED HP | 2 | ------ | 562251 |
| C403 | GALLEY-FWD/REFRIGER. | AMP HNL | 2 | 562248 | 562247 |
| C406 | FR JCT BDI COMPT.-WATI-SKID | AMP HNL | 2 | 560800 | 560898 |
| C407 | FR SERV.COMPT.-SIGN | AMP HNL | 2 | 560800 | 560898 |
| C408 | ENGINE COMPT.-SIGN | PED WP | 4 | 561686 | 561687 |
| C409 | ENGINE CPT.-LOW COOL.LEVEL | PED HP | 2 | 562358 | ------ |
| C410 | FR JCT BDI-DOOR CONNECTOR | AMP HNL | 15 | 561787 | 561786 |
| C412 | FR JCT BDI-DOOR CONNECTOR | AMP HNL | 15 | 561787 | 561786 |
| C412 | LH SW.PANEL-MASTER SWITCH | SWF | 8 | ------ | 561087 |
| C413 | ENG.CPT-A/C HI UNLOAD.PRS SW | PED WP | 2 | 561566 | 561569 |
| C414 | RR JCT BDI | AMP HNL | 9 | 560678 | 560669 |
| C416 | ENGINE CNSOLE-FAN SIGNAL | AMP HNL | 2 | 561781 | 561782 |
| C417 | ENGINE CNSOLE-FAN SIGNAL | AMP HNL | 2 | 561781 | 561782 |
| C417 | FRONT JCT BDI-CODECS | AMP HNL | 15 | 561787 | 561786 |
| C418 | INSTR.PANEL LH-HTR WINDOWS SW | SWF | 8 | ------ | 561087 |
| C419 | FR JCT BDI-DOOR CONN.FOR JACOB | AMP HNL | 3 | 561667 | 561558 |
| C420 | ENGINE COMPT.-WEBASTO WATER HTR | TC | 2 | 561597 | ------ |
| C421 | ENGINE COMPT.-WEBASTO WATER HTR | TC | 1 | 561873 | ------ |
| C422 | ENGINE COMPT.-WEBASTO WATER HTR | TC | 2 | 561597 | ------ |
| C423 | UNDER DASH-RH-DOOR CENTER | AMP HNL | 3 | 561667 | 561558 |
| C425 | ALARM JCT BDI-CODECS | AMP HNL | 15 | 561787 | 561786 |
| C426 | ALARM JCT BDI-CODECS | AMP HNL | 15 | 561787 | 561786 |
| C427 | ALARM JCT BDI-DOOR | AMP HNL | 6 | 561552 | 561555 |
| C430 | ALARM JCT BDI-COMPT.-TIMER | AMP FF | 8 | 561188 | 561363 |
| C431 | ALARM JCT BDI-DOOR-MEL.T.H.D | AMP HNL | 2 | 560800 | 560898 |
| C432 | ENGINE CPT.-PROV.SW.DOOR AJAR | DEUTSCH | 4 | 562479 | 562477 |
| C433 | FRONT JCT BDI-CONN.FL.PRESS.SW | AMP HNL | 3 | 561667 | 561558 |
| C434 | FRONT JCT BDI-CODECS | AMP HNL | 15 | 561787 | 561786 |
| C435 | FR SERVICE CPT.-RH KNEEL.PRS.SW | PED WP | 2 | 560800 | 560898 |
| C436 | RH HAT RACK-WCL CENTER ROOF A/C | AMP CPC | 16 | 560639 | 560640 |
| C437 | WORLD TRANSM.-MAIN CONNECTOR | DEUTSCH | 31 | 562572 | 562536 |
| C438 | WORLD TRANSM.-TURBINE SENSOR | PED HP | 2 | ------ | 562426 |
| C439 | WORLD TRANSM.-ENGINE SPS.SENS. | PED HP | 2 | ------ | 562426 |
| C440 | WORLD TRANSM.-SPEED SENSOR | ITT | 2 | ------ | 562541 |
| C441 | WORLD TRANSM.-RETARDER TEMP. | PED HP | 2 | 561566 | 561569 |
| C442 | WORLD TRANSM.-SOL.VALVE | PED HP | 2 | 561566 | 561569 |
| C443 | WORLD TRANSM.-SENSOR CONN. | DEUTSCH | 36 | 562578 | 562573 |
| C444 | RR JCT BDI-ODL CONN W.C. | PED HP | 12 | ------ | 562574 |

CONNECTORS CODE ID  Page G-2

| No. | LOCATION | #ND TYPE | *PIN CAVITY | *SOCKET HOUSING | HOUSING |
|---|---|---|---|---|---|
| C465 | LH CONSOLE-SHIFTER SELECTOR | T & BET | 18 | ------ | 562429 |
| C466 | FR SERVICE CPT.-RESIS.HOO. | PED WP | 3 | ------ | 562428 |
| C467 | FR SERVICE CPT.-RESIS.HOO. | PED WP | 3 | ------ | 562428 |
| C468 | FR SERV.COMPT.-WCL SW.L.T. | PED WP | 1 | ------ | 562873 |
| C470 | FR SERVICE CPT.-SILENT 1000 | AMP HNL | 2 | 562248 | 562247 |
| C471 | FR SERVICE CPT.-SILENT 1000 | AMP HNL | 2 | 562248 | 562247 |
| C472 | FR SERVICE CPT.-SILENT 1000 | PED HP | 2 | 561566 | 561569 |
| C473 | FR SERVICE CPT.-SILENT 1000 | AMP HNL | 2 | 560800 | 560898 |
| C474 | ALARM JCT BDI-PROPEVENT | HOLEX | 4 | 561478 | 562069 |
| C501 | LH CONSOLE-PROPEVER HOLDER | PED HP | 3 | 562433 | ------ |
| C502 | LH CONSOLE-PRE HEATER SW. | SWF | 8 | ------ | 561087 |
| C503 | LH CONSOLE-PRE