PREVOST CAR inc.

WIRING DIAGRAM

NO: D060871

P. 5 PRIOR

REVISION 000

ALARM AND SIGNAL

AIR DRYER

DIFFERENTIAL OIL TEMP.

LOW FUEL

FUEL WATER FILTER

ETHER COLD START

PARKING BRAKE SW.

RADIATOR FAN CLUTCH

CHASSIS GROUND

TAG AXLE PRESS SW. N.C.

LO-AIR PRIM. PRESS SW. N.C.

LO-AIR SEC. PRESS SW. N.C.

WATER TEMP. SENSOR

FUEL TANK UNIT

TRANSM. OIL TEMP. SENSOR

OIL PRESSUR SENSOR

HORN BUTTON

FIRE DETEC.

ELECTRICAL HORNS

OIL TEMP. SENSOR

TELL-TALE LT.

FUEL FILTER

ETHER SW.

PARK PRESSURE SW.

ETHER SOLENOID SW.

F.C.

SONALERT

R12

R78

R79

PIEZO

DETECTOR

WATER DETECT. MODULE

GAUGE WATER TEMP.

GAUGE FUEL

GAUGE OIL TEMP.

GAUGE OIL PRESS

GAUGE VOLTMETER

TAG AXLE T.T. LT.

LO-AIR PRIM. T.T. LT.

LO-AIR SEC. T.T. LT.

TELL-TALE LT.

TO WATER HEATER TIMER CONNECTOR SEE P.17

TO WATER HTR TIMER SEE P.17

TO FR. SERVICE CPT BOX ENGINE BRAKE SYSTEM SEE P.23

TO TACHOGRAPH SEE P.19

24V IGNITION FROM FR. JCT. PANEL JCT.*115 SEE P.2

TO 24V IGNITION INSTRUMENTATION

FROM DASH LTS. REOSTAT SEE P.11

TO LAVATORY EMERGENCY BUZZER SEE P.20

12V POWER FROM FR. JCT. PANEL 12V JCT. BLOCK SEE P.1

TO TACHOGRAPH SEE P.18

TO DIGITAL CLOCK SEE P.9

24V HOT WIRE FROM FR. JCT. PANEL JCT.*112 SEE P.1

24V IGNITION FROM FR. JCT. PANEL JCT.*115 SEE P.2

FROM DASH LTS. RHEOSTAT SEE P.11

24V IGNITION FROM BAT. JCT. BOX JCT* 10 SEE P.1

TO DAYTIME RUN LT. FR. JCT. PANEL DIODE D19 SEE P.6

TO FAST IDLE SW. SEE P.3

24V IGNITION FROM RR. JCT. BOX JCT.*58 SEE P.2

FAN CTRL SPEED* 1 FROM DDEC3 ECM C161(A2) SEE P. 3

FAN CTRL SPEED* 2 DDEC3 ENGINE HARNESS