BATT. CPT
JCT BLOCK "C

BOSCH ALT. : 064729
DELCO ALT. : 064607

R54
R55

(00-16)
(00-12)
063906
TO DDEC 3
ECM GROUND
TO DDEC 3
BREAKERS
TO WORLD TR.
BREAKER
151-12
150A-12
150-12
12W-12
12W-12
064607 (136V-10)

GRD ELECTRONIC
JUNCTION BLOCK

12V ELECTRONIC
JUNCTION BLOCK

12V ELECTRICAL
JUNCTION BLOCK

(12-10)
(12-8)
(12I-10)
(12D-10)
(00-12)

BOSTER BLOCK
POSITIVE POST
+

BOSCH ALT. : 064729
DELCO ALT. : 064607

BATT. CPT
SAFETY CUT OUT SW
(OMR-18)
(OMS-18)
(OMS-18)

GROUND FROM DASH CUT OUT SW.
GROUND FROM GENERATOR RUN RLY (R78)

063595 (24A-2/0)
064607 (24D-10)
24V DISCONNECT
CUT OUT RLY
86
85

CHASSIS GROUND

065231 (101-4/0)
064741 (OSA-1/0)

FROM 24V BATTERY
SEE PAGE B2
063591 (24-4/0)

BATT. CPT
12V HOT WIRE
JCT BLOCK "A

063593 (24E-2/0)

ALTERNATOR
BOSCH
24V-140A
B-
B+

064740 (102A-1/0)
065297 (102-2/0)

GENERATOR
24V-270
DC+

065231 (101-4/0)
062214 (0C-2/0)
062212 (0B-2/0)
STARTER

BATT. CPT
24V HOT WIRE
JCT BLOCK "B

064607 (24D-10)

TO STARTER
RLY (R4)

(12D-10)
(12F-8)
(12R-10)
(12I-10)
(12IA-10)
(12I-10)
(IGNITION SIGNAL)
30
86
87
85
R2

CB5 30A
CB7 90A
CB8 150A
CB6 90A
CB2 40A
CB4 70A
CB3 40A
CB1 40A

(24VD-10)
(24VF-4)
(24VD-10)
(12VF-4)
(12VD-10)
(12VI-10)
(90D-1)
(90B-10)
(90C-10)
(24VR-4)
(12VF-4)
(12VR-4)
(12VD-10)
(12VI-10)

BATT. CPT
12V IGNITION
JCT BLOCK "E"

064992

EVAPORATOR
FAN JCT BLOCK
(90D-1)
CONDENSER
FAN RH MOTOR
(41-10)
CONDENSER
FAN LH MOTOR
(42-10)
CB77 40A
CB78 40A

065273

064488 (24VR-4)

(24VD-10)
(12VD-10)
(12VR-10)
(12VI-10)
(00-12)

0V BATT. | 24V | 24VD | 12V | 12VD | 12VI

FRONT JUNCTION BOX

24VD | 24V | 12VD | 12V | 12VI | 0V BATT.

REAR JUNCTION BOX

PREVOST	WIRING DIAGRAM	NO: D060912	PAGE: B1	REVISION 10