



DataTransit Installation Procedures

Axion Technologies Ltd.

Axion Document No.3041752

*The information contained in this document is the property of **AXION TECHNOLOGIES**. Except as specifically authorized in writing by **AXION TECHNOLOGIES**, the holder of this document shall: Keep all information contained here in confidential and shall protect same in whole or in part from disclosure and dissemination to all third parties and use the same for operating and maintenance purposes only.*

151, rue du Parc-de-l'Innovation, La Pocatière (Québec), Canada G0R 1Z0

Phone: (418) 856-1454 Fax: (418) 856-5978 E-mail: info@axiontech.ca – Internet: www.axiontech.ca

DataTransit Installation Procedures

Before you start

Whether you are installing DataTransit on a new computer or you are updating a previous version of DataTransit already installed on your computer, it is important to make a backup of the existing database files before you start the installation process.

The files to backup are found in the following folders (assuming a standard installation of the previous version of DataTransit):

- C:\Axion\Database (all files)
- C:\Axion\Pictogrm (all files)

Send these files to Axion Technologies, ([see contact information below](#)), to have them updated to fit the new DataTransit application. Axion Technologies will return the updated files (in a zip file format) which will be required to finalize the installation.

Installation package preparation

NOTE

Go through the following steps only if you are using the compressed (zip) DataTransit installation package received by email. Otherwise, go directly to Step 1 Installation.

1. Create a new folder on your C: drive (for example, C:\DataTransit_TEMP)
2. Copy the new DataTransit installation zip file and unzip its content in the folder previously created.
3. Rename the files as in the following table: *(Step 3 applicable only if you received the "Email" Installation Package)*

ZIP FILE NAME	NEW FILE NAME
DT(<i>version number</i>)-Setup.To Rename-EXE	DT(<i>version number</i>)-Setup.exe
For files in the BDE for Win 7 folder:	
• BDE For Win 7 Setup.To Rename-VBS	BDE For Win 7 Setup.vbs
• BdeInst.To Rename-DLL	BdeInst.dll
For files in the BDE for WinXP folder:	
• _INST32I.To Rename-EX_	_INST32I.ex_
• _ISDEL.To Rename-EXE	_ISDEL.exe
• BDE SETUP.To Rename-EXE	BDE SETUP.exe
• _SETUP.To Rename-DLL	_SETUP.dll
• SETUP.To Rename-INI	SETUP.ini
• SETUP.To Rename-INS	SETUP.ins

1. Installation

1.1. DataTransit installation

In order to install DataTransit, you must have the appropriate administrative access rights to your computer. The installation is done in three (3) steps as follows:

- 1.1.1 BDE Administrator installation.
- 1.1.2 DataTransit application installation.
- 1.1.3 Database files installation.

1.1.1 BDE Administrator Installation

NOTE

If you have an older version of DataTransit installed on your computer, go directly to the Step 1.1.2 DataTransit application installation.

BDE installation for Windows XP:

The BDE program installs like any other Windows program.

- Go to the folder “BDE for WinXP”.
- Run “BDE SETUP.EXE”.
- Follow the installation steps.

BDE installation for Windows 7:

- Go to the folder “BDE for Win 7”
- Run “BDE For Win 7 setup.VBS”.
- At the first dialog box, click “OK” to continue.
- Click “Yes” at the warning pop-up and click “OK” at the confirmation pop-up.

1.1.2 DataTransit application installation

WARNING

At this step, if you are updating DataTransit on a computer where it is already installed, the database files will be overwritten. Make sure that you made the backup as specified at the beginning of this document before you start this process.

- Go to the main folder previously created in the “Installation package preparation” section of this document.
- Run “DT(*version number*)-Setup.exe”.
- A Self-extracting dialog box will appear. Select the “Overwrite” radio button and click “Start”.

- Go to the folder C:\Axion. Create and place a shortcut of the file Dtranapp.exe on your computer's desktop.

1.1.3 Database files installation

- Create two (2) new folders in the DataTransit_TEMP folder:
 - ▲ For the database - C:\DataTransit_TEMP\Database
 - ▲ For the pictogram - C:\DataTransit_TEMP\Pictogrm
- Copy the .zip files received from Axion in the appropriate folder and unzip their content in the folder you just created.
- Copy* ALL unzipped database files in the following folder: C:\Axion\Database
- Copy* ALL unzipped pictogram files in the following folder: C:\Axion\Pictogrm

* At the warning pop-up, click "YES TO ALL" to overwrite the files.

Your installation is now complete.

The password to access the software is "axion". Please delete the DataTransit_TEMP folder as it is no longer required.

Assistance

If you need assistance, please contact:

CONTACT INFORMATION	
<p>Sales : Jean-Patrice Hudon @ : jean-patrice.hudon@axiontech.ca ☎ : 1 + 418 856-1454, # 2146</p>	<p>Customer Service : Guy Arsenault @ : guy.arsenault@axiontech.ca ☎ : 1 + 418 856-1454, # 2182</p>

Axion Technologies Ltd
 151 rue du Parc-de-l'Innovation
 La Pocatière, Québec, G0R 1Z0, Canada
 ☎ : 1 + 418 856-1454
 ☎ : 1 + 418 856-5978

Revision History

Revision Level	Date	Change Description
P1	2011-11-23	First draft
--	2011-11-28	Original draft: <ul style="list-style-type: none"> • Minor modifications to wording • Minor modifications to format
A	2012-02-16	- Changed contact Information - Minor addition to text - Changed title