

MULTIPLEX INPUT LIST

Module.Pin#	Signal name	Ignition Key switch	Page	Connected devices
A36.JA:11	I_IgnKeySw	Ignition Key switch		
A36.JA:12	I_HazardSw	Hazard Switch		
A36.JA:13	I_EntDorOpSw	Entrance Door Open Switch		
A36.JA:14	I_FireSensorA36	Fire Sensor On A36		
AE.	I_A41_NormalMode			
AE.	I_A44_NormalMode			
AE.	I_A45NormalMode			
AE41.J1:17	I_ParkBrSe	Paking Brake Sensor	12.1	
AE41.J1:2	I_StartEna2		3.2	
AE41.J1:20	I_AFSSOvrRide			
AE41.J1:21	I_BrakePedSec		12.1	
AE41.J2:1	I_StartEna3		3.2	
AE41.J2:10	I_3rdLuggDorOpLH		25.1	
AE41.J2:11	I_FrSrvCptOpenSe		25.1	
AE41.J2:12	I_5thLugDorOpRH		25.1	
AE41.J2:13	I_5thLuggDorOpLH		25.1	
AE41.J2:2	I_FireExt2ndAlm		38.1	
AE41.J2:3	I_FrEngStaSw	Front Engine Start Switch	3.2	Sw83:2
AE41.J2:4	I_1stLuggDorOpLH		25.1	
AE41.J2:5	I_FireExt1stAl		38.1	
AE41.J2:6	I_1stLuggDorOpRH		25.1	
AE41.J2:7	I_2ndLuggDorOpRH		25.1	
AE41.J2:8	I_2ndLuggDorOpLH		25.1	
AE41.J2:9	I_3rdLuggDorOpRH		25.1	
AE42.J1:2	I_LowHiBuoySw		32.1	
AE42.J1:20	I_TgAxlSw	Tag Axle Switch	32.1	
AE42.J1:21	I_PrkBrkRelSw	Park Brake Release Switch	32.1	
AE42.J1:5	I_KneeSw		32.1	
AE42.J2:1	I_KneeLevelSe		32.1	
AE42.J2:3	I_InverterSw		40.1	sym870_304:8
AE42.J2:4	I_TagCtrl		32.1	
AE42.J2:6	I_TrailerPrkBkSe		12.2	
AE42.J2:7	I_TrailerPrkBkSw		12.2	Sw40:B
AE43.J2:5	I_LuggDrLkSe		33.1	
AE43.J2:8	I_ServDoorLockSe		33.1	
AE43.J2:9	I_SnowChains			
AE44.J2:5	I_SunVisorDrv	sun visor drv sw	41.1	
AE44.J2:6	I_SunVisorPass	sun visor pass sw	41.1	
AE45.J2:5	I_CadecCrankDis	Cadec Crank Disable	60.4	
AE46.J1:20	I_PassColorSeq		23.1	
AE47.J1:20	I_WipWshLowLvl		34.1	
AE47.J1:21	I_LHFFlshSwLHom		26.1	
AE48.J1:20	I_EntDorOpSe	Entrance Door Open Sensor	29.1	Se50:4

MULTIPLEX INPUT LIST

Module.Pin#	Signal name	Ignition Key switch	Page	Connected devices
AE48.J1:21	I_EntDorLockSw	VIP Entrance Door Lock Switch		
AE48.J1:24	I_BatMonMod48			
AE48.J2:5	I_IntDorOpSw	Entrance Door Open Switch	29.1	
AE48.J2:6	I_IncrEncoder		29.1	Mo1:5
AE48.J2:8	I_IntDorClSw		29.1	
AE48.J2:9	I_EntDorClSe	Entrance Door Close Sensor	29.1	
AE49.J1:20	I_M1MotorRunning		34.1	A21.A:1
AE49.J1:21	I_RHFlshSwLHom		26.1	
AE49.J2:11	I_DrvTempSe	Driver Temperature sensor	18.1	Se21:B
AE50.J1:20	I_AltSeUR		1.1	
AE50.J1:21	I_BattChrgSig		40.1	
AE50.J1:24	I_BatMonMod50			
AE50.J2:5	I_FnDrvCacDiag		13.1	
AE50.J2:6	I_FnDrvCoolDiag		13.1	
AE50.J2:8	I_RJBLtSw	Rear Junction Light Switch	25.1	
AE51.J1:20	I_RetdrSig	Retarder Signal	15.1	A1:24
AE52.J1:21	I_BrakePedPri		12.1	
AE52.J2:5	I_LHRrFlsh		26.2	
AE52.J2:6	I_RHRrFlsh		26.2	
AE53.J1:20	I_StartEna1		3.2	
AE53.J1:24	I_BatMonMod53			
AE53.J2:5	I_EngStaRrSw	Engine Start Rear Switch	3.2	
AE53.J2:6	I_EngDoorSe	Engine Door Sensor	25.1	
AE53.J2:8	I_AltSeLR		1.1	
AE53.J2:9	I_AltSeLL		1.1	
AE54.J1:24	I_BatMonMod54			
AE54.J2:11	I_SuperHeatSe		18.2	Se24:3
AE54.J2:8	I_AcPresHISse	Ac Pressure High Side Sensor	18.2	
AE54.J2:9	I_AcPresLoSse	Ac Pressure Low Side Sensor	18.2	Se24:2
AE55.J1:2	I_ExtLightSe		26.1	Se16:B
AE55.J2:1	I_DrvLtSw	Driver Light Switch	19.1	Sw24:8
AE55.J2:11	I_RoofHatchFanSw		18.5	Sw162.A:6
AE55.J2:2	I_DimmerSw	Dash BackLighting	19.1	Sw161:2
AE55.J2:3	I_PassCtrlMode		23.1	Sw25:6
AE55.J2:4	I_ReadLightCtrl		22.1	Sw26:6
AE55.J2:5	I_CleaningMode		22.1	Sw23:8
AE55.J2:6	I_RetarderSel	Retarder Selected	12.1	Sw16:6
AE55.J2:7	I_WclSw	Wheel Chair Lift Dash Switch	36.1	Sw20:8
AE55.J2:9	I_PRRackFanSw	Parcel Rack Fan Switch	18.3	Sw27:8
AE56.J1:5	I_HdLtPos2Sw		26.1	Sw2:8
AE56.J2:11	I_HoodDoorOpSe			
AE56.J2:5	I_FogLightSw	Fog Lights Switch	26.5	Sw3:8
AE56.J2:7	I_HornSw	Horn Switch	9.1	A8:Air_Horn

MULTIPLEX INPUT LIST

[illegible]