Instruction Sheet

IS-20925A

CENTRAL HVAC MERV FILTERS INSTALLATION

Revision A	Info added: Optional metal frames available for kit 1 & 2	06-15-2021
------------	---	------------

APPLICATION

Part No.	Туре	Vehicles
IS20925-1	MERV 8	H345 from A-1470 and up, X345 from B-5002 up to D-5458
IS20925-2	MERV 13	NOTE: 370479 & 370480 metal frames available for first installation
IS20925-3	MERV 8	
IS20925-4	MERV 13	
IS20925-5	MERV 8	H345 from R-012 to 9-1469
IS20925-6	MERV 13	п 343 нон к-012 to 9-1469

NOTE

Filter change is recommended every <u>3 months for MERV13</u> filters and <u>every 6 months for MERV8</u> filters

OPTIONAL MATERIAL

Order the following reusable metal frames for the first installation of Kit # IS20925-1 & # IS20925-2:

Part No.	Description	Qty
370479	OPTIONAL AIR FILTER FRAME 1" X 38" X 10-1/2" ASS (1)	1
370480	OPTIONAL AIR FILTER FRAME 1" X 38" X 10-1/2" ASS (2)	1

MATERIAL

Kit # IS20925-1 includes the following parts*:

Part No.	Description	Qty
871466	CENTRAL UNIT MERV8 FILTER 1" X 38" X 10 1/2	2
IS-20925	INSTRUCTION SHEET (EN)	1
FI-20925	INSTRUCTION SHEET (FR)	1

* 370479 & 370480 Optional metal frames available for first installation

Kit # **IS20925-2** includes the following parts*:

Part No.	Description	Qty
870142	CENTRAL UNIT MERV13 FILTER 1" X 38" X 10 1/2	2
IS-20925	INSTRUCTION SHEET (EN)	1
FI-20925	INSTRUCTION SHEET (FR)	1

* 370479 & 370480 Optional metal frames available for first installation

Kit # IS20925-3 includes the following parts:

Part No.	Description	Qty
870144	CENTRAL UNIT MERV8 FILTER 1" X 38" X 21"	1
IS-20925	INSTRUCTION SHEET (EN)	1
FI-20925	INSTRUCTION SHEET (FR)	1

Kit # IS20925-4 includes the following parts:

Part No.	Description	Qty
870145	CENTRAL UNIT MERV13 FILTER 1" X 38" X 21"	1
IS-20925	INSTRUCTION SHEET (EN)	1
FI-20925	INSTRUCTION SHEET (FR)	1

Kit **# IS20925-5** includes the following parts:

Part No.	Description	Qty
870146	CENTRAL UNIT MERV8 FILTER 1" X 23 3/8" X 43 1/2"	1
IS-20925	INSTRUCTION SHEET (EN)	1
FI-20925	INSTRUCTION SHEET (FR)	1

Kit # IS20925-6 includes the following parts:

Part No.	Description	Qty
870147	CENTRAL UNIT MERV13 FILTER 1" X 23 3/8" X 43 1/2"	1
IS-20925	INSTRUCTION SHEET (EN)	1
FI-20925	INSTRUCTION SHEET (FR)	1

NOTE

Material can be obtained through regular channels.

PROCEDURE



DANGER


Park vehicle safely, apply parking brake, stop engine. Prior to working on the vehicle, set the ignition switch to the OFF position and trip the main circuit breakers equipped with a trip button. On Commuter type vehicles, set the battery master switch (master cut-out) to the OFF position.


Lock out & Tag out (LOTO) must be performed during set-up, maintenance or repair activities. Refer to your local procedure for detailed information regarding the control of hazardous energy.



CAUTION

All waste coming from the filters must be considered as <u>potentially contaminated</u> (dust and particles). *Handle accordingly & wear proper personal protection equipment (PPE).*






STANDARD AIR FILTER INSTALLATION (ALL KITS)

1. Remove (drill out) all small rivets present around the filter metal frame (metal frame will be reused).





2. Unbent the metal frame locking tab located at one of the frame corners and open the metal frame to free the filter element.



3. Remove the filter from the frame.




4. Push flat all metal tabs inside the frame rail.



5. Insert the MERV filter in the frame rail. Take note of the airflow direction of the filter.


NOTE: Arrow and/or mesh side of the filter must be pointing/facing the <u>outside</u> of the vehicle.



- 6. Reassemble the metal frame (insert and bent back the locking tab).
- 7. Reinstall the filter(s) making sure that the screen mesh is facing the outside of the vehicle.









PARTS / WASTE DISPOSAL

Discard according to applicable environmental regulations (Municipal/State[Prov.]/ Federal)

Place old filters in plastic bags & follow current health agencies recommendation regarding potentially contaminated waste disposal.