

PREVOST

ENREGISTRÉ - REGISTERED
ISO 9001 & ISO 14001


WARRANTY BULLETIN

Wb10-04



DATE : JANUARY 2010	SECTION : 06 - Electrical
EXPIRATION: JANUARY 2012	
SUBJECT : PROPER RUBBING PROTECTION FOR THE JUMP-STARTING POSITIVE TERMINAL BLOCK CABLE	

APPLICATION

Model	VIN	
X3-45 Coaches Model Year : 2007 - 2009	From 2PCG334947102 8754 up to 2PCG334929C72 9767 incl.	
<p>This bulletin does not necessarily apply to all the above-mentioned vehicles, some vehicles may have been modified before delivery. The owners of the vehicles affected by this bulletin will be advised by a letter indicating the Vehicle Identification Number (VIN) of each vehicle concerned.</p>		

DESCRIPTION

On the vehicles affected by this bulletin, it is necessary to inspect the jump-start terminal block cable. It is very important that the cable be covered with a protective sleeve to protect from rubbing, especially where it is secured with a nylon tie. Refer to the following procedure to validate correctness of the installation.

Consult or download a PDF version of this bulletin on Prevost Web site at the following address:
<http://prevostparts.volvo.com/technicalpublications/en/pub.asp>

MATERIAL

Order the following parts if necessary:

Part No.	Description	Qty
504637	Nylon tie 368mm (medium)	2
562218	Convuluted tubing, 12" long	1

NOTE

Material can be obtained through regular channels.




DANGER

Park vehicle safely, apply parking brake, stop engine and set battery master switch(es) to the OFF position prior to working on the vehicle.

PROCEDURE

1. Open the door giving access to the R.H. side of the engine and locate the positive (red) jump-start terminal block.



2. Check that the protective sleeve covers the cable up to about 2 inches from the terminal. It is very important for the cable to be protected from rubbing at the point where it is secured with the nylon tie (see figure below).
3. If the jump-start positive terminal block cable is not properly protected, order part #562218.
4. When proceeding with the installation of the protective sleeve, it is not necessary to disconnect the cable. Simply slit the sleeve using scissors and place it over the cable.
5. Make sure that the cable is properly covered with the protective sleeve at the point of attachment.
6. Finally, secure the cable using a nylon tie.

WARRANTY

This modification is covered by Prevo's normal warranty. We will reimburse you the parts and 1/4 of hour (0.25) of labor for the inspection and an additional 1/4 of hour (0.25) of labor if the repair was necessary upon receipt of a completed A.F.A. form on which you must specify as per "Warranty Bulletin 10-04".